



XT600Z(U)'88

3AJ-AE1

SUPPLEMENTARY SERVICE MANUAL



FOREWORD

This Supplementary Service Manual has been prepared to introduce new service and new data for the XT600Z. For complete information on service procedures, it is necessary to use this Supplementary Service Manual together with following manual.

XT600 Service Manual 2KF-ME1

**XT600Z(U)
SUPPLEMENTARY SERVICE MANUAL
©1987 by Yamaha Motor Co., Ltd.
1st Edition, November 1987
All rights reserved. Any reprinting or
unauthorized use without the written
permission of Yamaha Motor Co., Ltd.
is expressly prohibited.
Printed in Japan**

NOTICE

This manual was written by the Yamaha Motor Company primarily for use by Yamaha dealers and their qualified mechanics. It is not possible to put an entire mechanic's education into one manual, so it is assumed that persons using this book to perform maintenance and repairs on Yamaha motorcycles have a basic understanding of the mechanical concepts and procedures inherent in motorcycle repair technology. Without such knowledge, attempted repairs or service to this model may render it unfit to use and/or unsafe.

Yamaha Motor Company, Ltd. is continually striving to improve all models manufactured by Yamaha. Modifications and significant changes in specifications or procedures will be forwarded to all Authorized Yamaha dealers and will, where applicable, appear in future editions of this manual.

TECHNICAL PUBLICATIONS
SERVICE DEVISION
MOTORCYCLE GROUP
YAMAHA MOTOR CO., LTD.

HOW TO USE THIS MANUAL

PARTICULARLY IMPORTANT INFORMATION

This material is distinguished by the following notation.

NOTE: A **NOTE** provides key information to make procedures easier or clearer.

CAUTION:

A **CAUTION** indicates special procedures that must be followed to avoid damage to the motorcycle.

WARNING:

A **WARNING** indicates special procedures that must be followed to avoid injury to a motorcycle operator or person inspecting or repairing the motorcycle.

MANUAL FORMAT





















All of the procedures in this manual are organized in a sequential, step-by-step format. The information has been compiled to provide the mechanic with an easy to read, handy reference that contains comprehensive explanations of all disassembly, repair, assembly, and inspection operations.

In this revised format, the condition of a faulty component will precede an arrow symbol and the course of action required will follow the symbol, e.g.,

- Bearings
Pitting/Damage → Replace.

EXPLODED DIAGRAM

Each chapter provides exploded diagrams before each disassembly section for ease in identifying correct disassembly and assembly procedures.

① GEN INFO 	② SPEC 
③ INSP ADJ 	④ ENG 
⑤ COOL 	⑥ CARB 
⑦ CHAS 	⑧ ELEC 
⑨ TRBL SHTG ?	⑩ 
⑪ 	⑫ 
⑬ 	⑭ 
⑮ 	⑯ 
⑰ 	⑱ 
⑳ 	㉑ 
㉒ 	

ILLUSTRATED SYMBOLS (Refer to the illustration)

Illustrated symbols ① to ⑨ are designed as thumb tabs to indicate the chapter's number and content.

- ① General information
- ② Specifications
- ③ Periodic inspection and adjustment
- ④ Engine
- ⑤ Cooling system
- ⑥ Carburetion
- ⑦ Chassis
- ⑧ Electrical
- ⑨ Troubleshooting

Illustrated symbols ⑩ to ⑯ are used to identify the specifications appearing in the text.

- ⑩ Filling fluid
- ⑪ Lubricant
- ⑫ Special tool
- ⑬ Tightening
- ⑭ Wear limit, clearance
- ⑮ Engine speed
- ⑯ Ω , V, A

Illustrated symbols ⑰ to ㉓ in the exploded diagram indicate grade of lubricant and location of lubrication point.

- ⑰ Apply engine oil
- ⑱ Apply gear oil
- ⑲ Apply molybdenum disulfide oil
- ⑳ Apply wheel bearing grease
- ㉑ Apply lightweight lithium-soap base grease
- ㉒ Apply molybdenum disulfide grease
- ㉓ Apply locking agent (LOCTITE®)




CONTENTS

GENERAL INFORMATION	1
MOTORCYCLE IDENTIFICATION	1
FRAME SERIAL NUMBER	1
ENGINE SERIAL NUMBER	1
SPECIFICATIONS	2
GENERAL SPECIFICATIONS	2
MAINTENANCE SPECIFICATIONS	5
ENGINE	5
CHASSIS	13
ELECTRICAL	17
GENERAL TORQUE SPECIFICATIONS	20
DEFINITION OF UNITS	20
LUBRICATION POINTS AND LUBRICANT TYPE	21
LUBRICATION DIAGRAM	23
CABLE ROUTING	27
PERIODIC INSPECTION AND ADJUSTMENT	31
INTRODUCTION	31
PERIODIC MAINTENANCE/LUBRICATION INTERVALS	31
SEAT, FUEL TANK AND COVERS	33
REMOVAL	33
INSTALLATION	34
ENGINE	34
ENGINE OIL LEVEL INSPECTION	34
ENGINE OIL REPLACEMENT	35
CLUTCH ADJUSTMENT	39
AIR FILTER CLEANING	41
FUEL LINE INSPECTION	42
ENGINE OIL TANK STRAINER CLEANING	43
ELECTRICAL	46
BATTERY INSPECTION	46
HEADLIGHT BULB REPLACEMENT	48
HEADLIGHT BEAM ADJUSTMENT	49
HEADLIGHT BEAM VARIATION	49
ENGINE OVERHAUL	50
DISASSEMBLY	50
STARTER MOTOR	50
MAGNETO ROTOR AND STARTER GEARS	51
INSPECTION AND REPAIR	53
STARTER DRIVES	53
ASSEMBLY AND ADJUSTMENT	57
STARTER GEARS AND MAGNETO ROTOR	57
STARTER MOTOR	59

FUEL PUMP	62
PUMP OPERATION INSPECTION	62
FUEL PUMP INSPECTION	62
FRONT FORK	66
REMOVAL	67
DISASSEMBLY	68
INSPECTION	70
ASSEMBLY	71
INSTALLATION	74
ELECTRICAL	77
XT600Z(U) CIRCUIT DIAGRAM	77
ELECTRICAL COMPONENTS	79
IGNITION AND STARTING SYSTEM	81
TROUBLESHOOTING	81
LOCATION OF PARTS-CONNECTORS	82
GENERAL INFORMATION	83
IGNITION AND STARTING CIRCUIT SYSTEM	84
INSPECTION PARTS	85
STARTER MOTOR	98
LIGHTING SYSTEM	103
CIRCUIT DIAGRAM	103
TROUBLESHOOTING	105
LIGHTING SYSTEM CHECK	108

XT600Z(U) WIRING DIAGRAM

GENERAL INFORMATION



MOTORCYCLE IDENTIFICATION

FRAME SERIAL NUMBER


The frame serial number ① is stamped into the right side of the steering head pipe.

Starting Serial Number:

XT600Z	3AJ-000101
XT600Z	3AJ-031101
XT600Z	3AJ-033101
XT600Z	3DS-000101
XT600ZU	3DE-000101

ENGINE SERIAL NUMBER

The engine serial number ① is stamped into the elevated part of the right rear section of the engine.



Starting Serial Number:

XT600Z	3AJ-000101
XT600Z	3AJ-031101
XT600Z	3AJ-033101
XT600Z	3DS-000101
XT600ZU	3DE-000101

NOTE:

- The first three digits of these numbers are for model identifications; the remaining digits are the unit production number.
- Designs and specifications are subject to change without notice.



SPECIFICATIONS

(D): For Germany (SF): For Finland
 (DK): For Denmark (F): For France
 (N): For Norway (I): For Italy
 (S): For Sweden (B): For Belgium
 (GB): For England (GR): For Greece
 (E): For Spain (CH): For Switzerland
 (NL): For Holland (P): For Portugal
 (O): For Oceania and S. Africa

GENERAL SPECIFICATIONS

Model	XT600Z(U)
Model Code Number:	3AJ1 (D)(F)(I)(B)(GB)(S)(GR)(P) 3AJ2 (E) 3AJ3 (NL)(N)(SF)(DK) 3DS1 (CH) 3DE1 (O)
Engine Starting Number:	3AJ1-000101 3AJ2-031101 3AJ3-033101 3DS1-000101 3DE1-000101
Frame Starting Number:	3AJ1-000101 3AJ2-031101 3AJ3-033101 3DS1-000101 3DE1-000101
Dimensions:	
Overall Length	2,210 mm (87.0 in) 2,290 mm (90.2 in) (D) (S) (DK) (N) 2,340 mm (92.1 in) (SF)
Overall Width	835 mm (32.9 in)
Overall Height	1,340 mm (52.8 in)
Seat Height	890 mm (35.0 in)
Wheelbase	1,460 mm (57.5 in)
Minimum Ground Clearance	255 mm (10.0 in)
Basic Weight:	
With Oil and Full Fuel Tank	185 kg (408 lb)
Minimum Turning Radius:	2,300 mm (90.6 in)
Engine:	
Engine Type	Air cooled 4-stroke, SOHC
Cylinder Arrangement	Forward inclined single cylinder
Displacement	595 cm ³
Bore × Stroke	95 × 84 mm (3.74 × 3.31 in)
Compression Ratio	8.5 : 1
Compression Pressure	
Standard	1,100 kPa (11 kg/cm ² 156 psi)
Starting System	Electric starter

GENERAL SPECIFICATIONS

SPEC



Model	XT600Z(U)
Lubrication System: Type Engine Oil Type Oil Capacity: Periodic Oil Change With Oil Filter Replacement Total Amount Oil Tank Capacity	Dry sump SAE 20W40 type SE motor oil or SAE 10W30 type SE motor oil 1.9 L (1.7 Imp qt, 2.0 US qt) 2.0 L (1.8 Imp qt, 2.1 US qt) 2.4 L (2.1 Imp qt, 2.5 US qt) 1.7 L (1.5 Imp qt, 1.8 US qt)
Air Filter: Type Oil Type	Wet type element Foam-air-filter oil or SAE 10W30 motor oil
Fuel: Type Fuel Tank Capacity Fuel Reserve Amount	Regular gasoline 23.0 L (5.1 Imp gal, 6.1 US gal) 3.1 L (0.7 Imp gal, 0.8 US gal)
Carburetor: Type/Quantity Manufacturer	Y27PV/1 pc. TEIKEI
Spark Plug: Type/Plug Gap Manufacturer	DPR7EA-9/0.8~0.9 mm (0.031~0.035 in) DPR8EA-9/0.8~0.9 mm (0.031~0.035 in) NGK
Clutch: Type	Wet, multiple-disc
Transmission: Type Operation Primary Reduction System Primary Reduction Ratio Secondary Reduction System Secondary Reduction Ratio Gear Ratio:	Constant mesh 5-speed Left foot operation Spur gear 74/31 (2.387) Chain drive 38/15 (2.533) (CH) 40/15 (2.677) (D)(F)(I)(B)(GB)(S)(E)(NL)(N)(SF)(DK) 1st 31/12 (2.583) 2nd 27/17 (1.588) 3rd 24/20 (1.200) 4th 21/22 (0.954) 5th 19/24 (0.792)
Chassis: Frame Type Caster Angle Trail	Diamond 27.5° 109 mm (4.29 in)



Model	XT600Z(U)	
Tire:		
Type	With tube	
Size:	Front	3.00S21-4PR
	Rear	4.60S18-4PR
		120/80-18-62P (IRC)
Manufacturer:	Front	BRIDGESTONE (TW25)
		IRC (GP110)
	Rear	BRIDGESTONE (TW26)
		IRC (GP110)
Tire Pressure (Cold tire):		
Maximum Load*	180 kg (397 lb)	
	(Front)	34 kg (75 lb)
	(Rear)	146 kg (322 lb)
Cold Tire Pressure	Front	Rear
Up to 90 kg (198 lb) load*	150 kPa (1.5 kg/cm ² , 21 psi)	150 kPa (1.5 kg/cm ² , 21 psi)
90 kg (198 lb) ~ Maximum load*	150 kPa (1.5 kg/cm ² , 21 psi)	180 kPa (1.8 kg/cm ² , 26 psi)
Off-road riding	100 kPa (1.0 kg/cm ² , 14 psi)	100 kPa (1.0 kg/cm ² , 14 psi)
High speed riding	150 kPa (1.5 kg/cm ² , 21 psi)	150 kPa (1.5 kg/cm ² , 21 psi)
*Load is total weight of cargo, rider, passenger, and accessories.		
Brake:		
Front Brake Type	Single disc brake	
Front Brake Operation	Right hand operation	
Rear Brake Type	Single disc brake	
Rear Brake Operation	Right foot operation	
Suspension:		
Front	Telescopic fork	
Rear	Swingarm (New Monocross)	
Shock Absorber:		
Front	Coil—Air spring/Oil damper	
Rear	Coil—Gas spring/Oil damper	
Wheel Travel:		
Front	255 mm (10.0 in)	
Rear	225 mm (8.9 in)	
Electrical:		
Ignition System	CDI	
Generator System	A.C. magneto generator	
Battery Type	GM12AZ	
Battery Capacity	12V, 12AH	
Headlight Type	Quartz bulb (Halogen)	
	(D)(B)(S)(E)(F)(GR)(P)(GB)(O)	
	Bulb type (I)(DK)(SF)(NL)(CH)(N)	

GENERAL SPECIFICATIONS




SPEC



Model	XT600Z(U)
Bulb Wattage (Quantity): Headlight Tail/Brake Light Flasher Light Auxiliary Light Meter Light "NEUTRAL" indicator Light "HIGH BEAM" indicator Light "TURN" indicator Light	12V 60W/55W (1 pc.) (D)(E)(B)(S)(F)(GR)(P) 12V 55W (1 pc.) 12V 35W/35W (2 pcs.) (I)(DK)(GB)(O)(SF)(NL) 12V 60W/55W (1 pc.) (CH)(N) 12V 5W/21W (1 pc.) 12V 21W (4 pcs.) 12V 4W (1 pc.) (D)(E)(B)(S)(F)(GR)(P)(SF)(NL)(CH)(N) 12V 4W (2 pcs.) (I)(DK) 12V 3.4W (2 pcs.) (GB) (O) 12V 3.4W (2 pcs.) 12V 3.4W (1 pc.) 12V 3.4W (1 pc.) 12V 3.4W (1 pc.)

MAINTENANCE SPECIFICATIONS

ENGINE


Model	XT600Z(U)
Cylinder Head: Warp Limit 	0.03 mm (0.0012 in) * Lines indicate straightedge measurement.
Cylinder: Bore Size < Wear Limit > Measuring Point (a) 	94.97 ~ 95.02 mm (3.739 ~ 3.741 in) < 95.1 mm (3.744 in) > 40 mm (1.6 in)
Camshaft: Drive Method Camshaft Outside Diameter Shaft-to-cap Clearance Cam Dimensions Intake "A" "B" "C" Exhaust "A" "B" "C" 	Chain drive (Left) 22.967 ~ 22.980 mm (0.904 ~ 0.905 in) 0.020 ~ 0.054 mm (0.0008 ~ 0.0021 in) 36.52 ~ 36.62 mm (1.438 ~ 1.442 in) 30.01 ~ 30.11 mm (1.181 ~ 1.185 in) 6.51 mm (0.256 in) 36.70 ~ 36.80 mm (1.445 ~ 1.449 in) 30.07 ~ 30.17 mm (1.184 ~ 1.188 in) 6.63 mm (0.261 in) 0.03 mm (0.0012 in)
Camshaft Runout Limit	0.03 mm (0.0012 in)



MAINTENANCE SPECIFICATION

SPEC



Model	XT600Z(U)	
Cam Chain: Cam Chain Type Number of Links Cam Chain Adjustment Method	75 – 010 126 Links Automatic	
Rocker Arm/Rocker Arm Shaft: Rocker Arm Inside Diameter Shaft Outside Diameter Arm-to-shaft Clearance	12.000 ~ 12.018 mm (0.472 ~ 0.473 in) 11.976 ~ 11.991 mm (0.471 ~ 0.472 in) 0.009 ~ 0.042 mm (0.0003 ~ 0.002 in)	
Valve, Valve Seat, Valve Guide: Valve Clearance (Cold): Intake Exhaust	0.07 ~ 0.12 mm (0.003 ~ 0.005 in) 0.12 ~ 0.17 mm (0.005 ~ 0.007 in)	
Valve Dimensions:	Intake	Exhaust
“A” Head Diameter	36.9 ~ 37.1 mm (1.45 ~ 1.46 in)	31.9 ~ 32.1 mm (1.25 ~ 1.26 in)
“B” Face Width	2.26 mm (0.09 in)	←
“C” Seat Width	1.0 ~ 1.2 mm (0.04 ~ 0.05 in)	←
“D” Margin Thickness	1.0 ~ 1.4 mm (0.04 ~ 0.06 in)	0.8 ~ 1.2 mm (0.03 ~ 0.05 in)
		
Stem Outside Diameter: Intake Exhaust Guide Inside Diameter: Intake Exhaust Stem-to-guide Clearance: Intake Exhaust Stem Runout Limit Valve Seat Width: Intake Exhaust	6.975 ~ 6.990 mm (0.274 ~ 0.275 in) 6.955 ~ 6.970 mm (0.273 ~ 0.274 in) 7.000 ~ 7.012 mm (0.275 ~ 0.276 in) 7.000 ~ 7.012 mm (0.275 ~ 0.276 in) 0.010 ~ 0.037 mm (0.0004 ~ 0.001 in) 0.030 ~ 0.057 mm (0.001 ~ 0.002 in) 0.01 mm (0.0004 in) 1.0 ~ 1.2 mm (0.04 ~ 0.05 in) 1.0 ~ 1.2 mm (0.04 ~ 0.05 in)	


MAINTENANCE SPECIFICATION

SPEC



Model	XT600Z(U)	
<p>Valve Spring:</p> <p>Free Length:</p> <p style="padding-left: 20px;">Intake</p> <p style="padding-left: 20px;">Exhaust</p> <p>Set Length (Valve Closed):</p> <p style="padding-left: 20px;">Intake</p> <p style="padding-left: 20px;">Exhaust</p> <p>Direction of winding (Top View)</p> <p>Tilt Limit:</p> <p style="padding-left: 20px;">Intake</p> <p style="padding-left: 20px;">Exhaust</p>	<p>Inner Spring</p> <p>40.1 mm (1.58 in)</p> <p>40.1 mm (1.58 in)</p> <p>22.7 mm (0.89 in)</p> <p>22.7 mm (0.89 in)</p> <p>Clockwise</p> <p>2.5°/1.7 mm (0.07 in)</p> <p>2.5°/1.7 mm (0.07 in)</p>	<p>Outer Spring</p> <p>43.8 mm (1.72 in)</p> <p>43.8 mm (1.72 in)</p> <p>34.2 mm (1.35 in)</p> <p>34.2 mm (1.35 in)</p> <p>Counterclockwise</p> <p>←</p> <p>←</p>
<p>Piston:</p> <p>Piston Size "D"</p> <p>Measuring Point "H"</p> <p>Over Size 2nd</p> <p>Over Size 4th</p> <div style="text-align: center;"> </div> <p>Piston Off-set</p> <p>Piston Off-set Direction</p> <p>Piston-to-cylinder Clearance < Limit ></p>	<p>94.915 ~ 94.965 mm (3.737 ~ 3.739 in)</p> <p>5.0 mm (0.20 in)</p> <p>95.5 mm (3.760 in)</p> <p>96.0 mm (3.780 in)</p> <p>2.0 mm (0.08 in)</p> <p>Intake side</p> <p>0.045 ~ 0.065 mm (0.002 ~ 0.003 in)</p> <p>< 0.1 mm (0.004 in) ></p>	
<p>Piston Ring:</p> <p>Type:</p> <p style="padding-left: 20px;">Top Ring</p> <p style="padding-left: 20px;">2nd Ring</p> <p>Dimensions (B × T):</p> <p style="padding-left: 20px;">Top Ring</p> <div style="text-align: center;"> </div> <p style="padding-left: 20px;">2nd Ring</p> <div style="text-align: center;"> </div> <p style="padding-left: 20px;">Oil Ring</p> <div style="text-align: center;"> </div> <p>End Gap (Installed):</p> <p style="padding-left: 20px;">Top Ring</p> <p style="padding-left: 20px;">2nd Ring</p> <p style="padding-left: 20px;">Oil Ring</p>	<p>Barrel</p> <p>Plain</p> <p>B = 1.2 mm (0.047 in)</p> <p>T = 3.8 mm (0.150 in)</p> <p>B = 1.2 mm (0.047 in)</p> <p>T = 3.8 mm (0.150 in)</p> <p>B = 2.5 mm (0.098 in)</p> <p>T = 3.4 mm (0.134 in)</p> <p>0.30 ~ 0.45 mm (0.012 ~ 0.018 in)</p> <p>0.30 ~ 0.45 mm (0.012 ~ 0.018 in)</p> <p>0.20 ~ 0.70 mm (0.008 ~ 0.028 in)</p>	



Model	XT600Z(U)
Piston Ring: Side Clearance (Installed): Top Ring 2nd Ring	0.04 ~ 0.08 mm (0.002 ~ 0.003 in) 0.03 ~ 0.07 mm (0.001 ~ 0.003 in)
Crankshaft: Crank Width "A" Runout Limit "C" Big End Side Clearance "D" Small End Free Play "F"	 74.95 ~ 75.00 mm (2.950 ~ 2.953 in) 0.03 mm (0.0012 in) 0.25 ~ 0.75 mm (0.010 ~ 0.030 in) 0.8 ~ 1.0 mm (0.031 ~ 0.039 in)
Balancer: Drive Method	Spur gear
Clutch: Friction Plate: Thickness Quantity Wear Limit Friction Plate: Thickness Quantity Wear Limit Clutch Plate: Thickness Quantity Warp Limit Clutch Spring: Free Length Quantity Minimum Free Length Clutch Housing: Thrust Clearance Clutch Release Method	2.72 ~ 2.88 mm (0.107 ~ 0.113 in) 6 pcs. 2.6 mm (0.102 in) 2.94 ~ 3.06 mm (0.116 ~ 0.120 in) 2 pcs. 2.8 mm (0.110 in) 1.2 mm (0.047 in) 7 pcs. 0.2 mm (0.008 in) 34.6 mm (1.362 in) 5 pcs. 32.6 mm (1.283 in) 0.070 ~ 0.071 mm (0.003 in) Inner push, cam push
Transmission: Main Axle Runout Limit Drive Axle Runout Limit	0.08 mm (0.003 in) 0.08 mm (0.003 in)
Shifter: Type	Cam drum and guide bar

MAINTENANCE SPECIFICATION

SPEC



Model	XT600Z(U)	
Carburetor:	Except for Germany	For Germany
I.D. Mark	3AJ 10	3AJ 00
Main Jet (M.J.)		
Primary Carburetor	# 155	# 165
Secondary Carburetor	# 125	←
Main Air Jet (M.A.J.)		
Primary Carburetor	φ1.0	←
Secondary Carburetor	φ1.2	←
Jet Needle (J.N.)		
Primary Carburetor	5C47—3/5	5C48—3/5
Secondary Carburetor	5X76—3/5	5X76—3/5
Needle Jet (N.J.)	φ2.6	←
Cutaway (C.A.)	5.5	←
Pilot Outlet (P.O.)	φ0.8	←
Pilot Jet (P.J.)	#48	←
Bypass 1 (B.P.1)	φ1.0	←
Pilot Screw (P.S.)	1 5/8 turns out	←
Valve Seat Size (V.S.)	φ2.5	←
Starter Jet (G.S.)	#80	←
Fuel Level (F.L.)	5.0 ~ 7.0 mm (0.20 ~ 0.28 in)	←
Float Height (F.H.)	25.0 ~ 27.0 mm (0.98 ~ 1.06 in)	←
Engine Idle Speed	1,250 ~ 1,350 r/min	←
Lubrication System:		
Oil Filter:		
Type	Paper type	
Oil Pump:		
Type	Trochoid type	
Tip Clearance	0.12 mm (0.005 in)	
Side Clearance	0.03 ~ 0.08 mm (0.001 ~ 0.003 in)	
Bypass Valve Setting Pressure	80 ~ 120 kPa (0.8 ~ 1.2 kg/cm ² , 11 ~ 17 psi)	
Relief Valve Operating Pressure	80 ~ 120 kPa (0.8 ~ 1.2 kg/cm ² , 11 ~ 17 psi)	
Oil Pressure	13 kPa (0.13 kg/cm ² , 1.8 psi) at 1,300 r/min	
Pressure Checking Location	Oil cleaner chamber	



MAINTENANCE SPECIFICATION

SPEC






Model	XT600Z(U)				
Tightening torque:					
Part to be tightened	Thread size	Tightening torque			Remarks
		Nm	m•kg	ft•lb	
Cylinder head					
Flange bolt	M8 × 1.25	29	2.9	21	
Stud bolt	M10 × 1.25	20	2.0	14	
Hexagon socket head bolt	M6 × 1.0	10	1.0	7.2	
Stud bolt	M6 × 1.0	7	0.7	5.1	
Spark plug	M12 × 1.25	18	1.8	13	
Cylinder head cover					
Hexagon socket head bolt	M6 × 1.0	10	1.0	7.2	
Tappet cover (Intake)					
Hexagon socket head bolt	M6 × 1.0	10	1.0	7.2	
Tappet cover (Exhaust)	M32 × 1.5	12	1.2	8.7	
Gear unit (Tachometer)					
Hexagon socket head bolt	M6 × 1.0	10	1.0	7.2	
Flat head screw	M6 × 1.0	7	0.7	5.1	
Cylinder					
Cap nut	M8 × 1.25	22	2.2	16	
Nut	M10 × 1.25	42	4.2	30	
Hexagon nut	M10 × 1.25	42	4.2	30	
Hexagon socket head bolt	M6 × 1.0	10	1.0	7.2	
Balancer gear					
Hexagon nut	M16 × 1.0	60	6.0	43	
Rotor (A.C. magneto)					
Hexagon nut	M14 × 1.5	120	12.0	85	
Locknut (Valve clearance adjuster)					
Hexagon nut	M6 × 1.0	14	1.4	10	
Cam sprocket					
Flange bolt	M7 × 1.0	20	2.0	14	
Cam chain tensioner					
Hexagon socket head bolt	M6 × 1.0	10	1.0	7.2	
Blind plug	M16 × 1.0	20	2.0	14	
Flange bolt	M6 × 1.0	8	0.8	5.8	
Rocker arm shaft					
Hexagon socket head bolt	M6 × 1.0	10	1.0	7.2	
Oil pump					
Hexagon socket head bolt	M6 × 1.0	10	1.0	7.2	
Oil strainer					
Panhead screw	M6 × 1.0	7	0.7	5.1	
Drain plug (crankcase)	M14 × 1.5	30	3.0	22	
Oil cleaner cover					
Hexagon socket head bolt	M6 × 1.0	10	1.0	7.2	
Screw	M5 × 0.8	5	0.5	3.6	

MAINTENANCE SPECIFICATION

SPEC




Model	XT600Z(U)				Remarks
Part to be tightened	Thread size	Tightening torque			
		Nm	m•kg	ft•lb	
Oil hose					
Hexagon socket head bolt	M6 × 1.0	10	1.0	7.2	
Union nut	M16 × 1.5	50	5.0	36	
Delivery pipe					
Union bolt	M8 × 1.25	18	1.8	13	
Carburetor joint					
Bolt	M6 × 1.0	10	1.0	7.2	
Clamp (Carburetor joint)					
Screw	M4 × 0.7	2	0.2	1.4	
Air filter case					
Flange bolt	M6 × 1.0	10	1.0	7.2	
Exhaust pipe					
Flange nut	M6 × 1.0	10	1.0	7.2	
Exhaust pipe protector					
Bind head screw	M6 × 1.0	7	0.7	5.1	
Muffler protector					
Bind head screw	M6 × 1.0	7	0.7	5.1	
Band (Exhaust pipe and muffler)					
Flange bolt	M8 × 1.25	20	2.0	14	
Muffler					
Flange bolt	M8 × 1.25	40	4.0	29	
Crankcase					
Hexagon socket head bolt	M6 × 1.0	10	1.0	7.2	
Stud bolt	M10 × 1.25	20	2.0	14	
Clamp (C.D.I. magneto lead)					
Panhead screw	M6 × 1.0	7	0.7	5.1	
Crankcase cover (Right)					
Hexagon socket head bolt	M6 × 1.0	10	1.0	7.2	
Crankcase cover (Left)					
Hexagon socket head bolt	M6 × 1.0	10	1.0	7.2	
Stopper plate (Bearing)					
Flat head screw	M6 × 1.0	7	0.7	5.1	
Ratchet wheel guide					
Hexagon bolt	M6 × 1.0	10	1.0	7.2	
Pressure plate					
Flange bolt	M6 × 1.0	8	0.8	5.8	
Clutch boss					
Hexagon nut	M20 × 1.0	90	9.0	65	
Primary drive gear					
Hexagon nut	M20 × 1.0	120	12.0	85	
Push lever					
Panhead screw	M8 × 1.0	12	1.2	8.7	
Push rod					
Hexagon nut	M6 × 1.0	8	0.8	5.8	
Drive sprocket					
Hexagon nut	M18 × 1.0	110	11.0	80	



Model	XT600Z(U)				Remarks
Part to be tightened	Thread size	Tightening torque			
		Nm	m•kg	ft•lb	
Stopper plate (Oil seal) Hexagon bolt	M6 × 1.0	10	1.0	7.2	
Stopper lever Bolt	M6 × 1.0	10	1.0	7.2	
Change pedal Hexagon bolt	M6 × 1.0	10	1.0	7.2	
Stator coil Panhead screw	M6 × 1.0	7	0.7	5.1	
Pickup coil Panhead screw	M6 × 1.0	7	0.7	5.1	
Neutral switch	M10 × 1.25	20	2.0	14	
Starter motor Flange bolt	M6 × 1.0	10	1.0	7.2	


Tightening sequence:

Cylinder head




Crankcase

Right-hand



Left-hand



MAINTENANCE SPECIFICATION

SPEC



CHASSIS

Model	XT600Z(U)
Steering System: Bearing Type	Taper roller bearing
Front Suspension: Front Fork Travel Fork Spring Free Length < Minimum Free Length > Spring Rate/Stroke (K1) (K2) Optional Spring Oil Capacity Oil Level Oil Grade Enclosed Air Pressure: Standard Minimum ~ Maximum	255 mm (10.0 in) 603 mm (23.7 in) < 593 mm (23.3 in) > 2.25 N/mm (0.225 kg/mm, 12.6 lb/in)/ Zero ~ 76.0 mm (Zero ~ 3.0 in) 4.6 N/mm (0.46 kg/mm, 25.3 lb/in)/ 76.0 ~ 255 mm (3.0 ~ 10.0 in) No 517 cm ³ (18.2 Imp oz, 17.5 US oz) 120 mm (4.72 in) From top of inner tube fully compressed without spring Fork oil 10W or equivalent Zero kPa (Zero kg/cm ² , Zero psi) Zero ~ 100 kPa (Zero ~ 1.0 kg/cm ² , Zero ~ 14 psi)
Rear Suspension: Shock Absorber Travel Spring Free Length Fitting Length Spring Rate/Stroke Optional Spring Enclosed Gas Pressure	74 mm (2.9 in) 244.5 mm (9.6 in) 235 mm (9.3 in) 90 N/mm (9.0 kg/mm, 504 lb/in)/ Zero ~ 65.0 mm (0.0 ~ 2.6 in) No 1,500 kPa (15 kg/cm ² , 213 psi)
Swingarm: Free Play Limit Side Clearance	1.0 mm (0.039 in) at swingarm end Move swingarm end side to side. 0.3 mm (0.012 in) at swingarm pivot
Front Wheel: Type Rim Size Rim Material Rim Runout Limit: Vertical Lateral	Spoke wheel 1.60 × 21 Aluminum 2.0 mm (0.079 in) 2.0 mm (0.079 in)



Model	XT600Z(U)
Rear Wheel: Type Rim Size Rim Material Rim Runout Limit: Vertical Lateral	Spoke wheel MT2.50×18 Aluminum 2.0 mm (0.079 in) 2.0 mm (0.079 in)
Drive Chain: Type/Manufacturer Number of Links Chain Slack	DID 520V6/DAIDO 104 30~40 mm (1.18~1.57 in)
Front Disc Brake: Type Disc Outside Diameter Disc Thickness Pad Thickness <Wear Limit> Master Cylinder Inside Diameter Caliper Cylinder Inside Diameter Brake Fluid Type	Single 267 mm (10.5 in) 4.0 mm (0.16 in) 6.8 mm (0.27 in) <0.8 mm (0.03 in)> 12.7 mm (0.5 in) 38.1 mm (1.5 in) DOT No. 4 or DOT No. 3
Rear Disc Brake: Type Disc Outside Diameter Thickness Pad Thickness <Wear Limit> Master Cylinder Inside Diameter Caliper Cylinder Inside Diameter Brake Fluid Type	Single 220 mm (8.66 in) 5.0 mm (0.20 in) 6.0 mm (0.24 in) <0.8 mm (0.03 in)> 12.7 mm (0.5 in) 34.9 mm (1.37 in) DOT No. 4 or DOT No. 3
Brake Lever and Pedal: Brake Lever Free Play Brake Pedal Position	2.0~5.0 mm (0.08~0.20 in) At end of brake lever. 5.0~10.0 mm (0.20~0.40 in) Below top of footrest.
Clutch Lever and Throttle Grip: Clutch Lever Free Play Throttle Cable Free Play	2.0~3.0 mm (0.08~0.12 in) At pivot of clutch lever. 2.0~5.0 mm (0.08~0.20 in) At grip flange.

MAINTENANCE SPECIFICATION

SPEC



Model	XT600Z(U)				
Tightening torque:					
Part to be tightened	Thread size	Tightening torque			Remarks
		Nm	m•kg	ft•lb	
Front fork/Handlebar:					
Handle crown and inner tube	M8 × 1.25	23	2.3	17	Refer to "NOTE"
Handle crown and steering shaft	M14 × 1.25	77	7.7	56	
Handlebar	M8 × 1.25	20	2.0	14	
Steering shaft and ring nut	M25 × 1.0	6	0.6	4.3	
Clamp (Front brake hose)	M8 × 1.25	10	1.0	7.2	
Master cylinder cap (Front brake)	M4 × 0.7	2	0.2	1.4	
Cowling stay and frame	M6 × 1.0	23	2.3	17	
Cowling stay and cowling	M6 × 1.0	7	0.7	5.1	
Meter mounting bolt	M8 × 1.0	7	0.7	5.1	
Horn and frame	M6 × 1.0	7	0.7	5.1	
Main switch and handle crown	M6 × 1.0	7	0.7	5.1	
Handlebar holder	M10 × 1.25	7	0.7	5.1	
Cable holder (Speedometer cable)	M5 × 0.8	1	0.1	0.7	
Cowling and fuel tank	M5 × 0.8	4	0.4	2.9	
Windscreen and cowling	M5 × 0.8	1	0.1	0.7	
Engine mount:					
Engine stay (Front) and frame	M10 × 1.25	64	6.4	46	
Engine stay (Front) and engine	M10 × 1.25	64	6.4	46	
Engine stay (Upper) and frame	M10 × 1.25	64	6.4	46	
Engine stay (Upper) and engine	M10 × 1.25	64	6.4	46	
Engine (Rear) and frame	M10 × 1.25	64	6.4	46	
Engine protector and frame	M6 × 1.0	10	1.0	7.2	
Rear shock absorber/Swingarm:					
Pivot shaft	M14 × 1.5	85	8.5	61	
Swingarm and relay arm	M12 × 1.25	59	5.9	43	
Relay arm and connecting rod	M10 × 1.25	32	3.2	23	
Connecting rod and frame	M10 × 1.25	32	3.2	23	
Rear shock absorber and frame	M12 × 1.25	59	5.9	43	
Chain tensioner	M8 × 1.25	23	2.3	17	
Chain case and swingarm	M6 × 1.0	4	0.4	2.9	
Chain protector and swingarm	M6 × 1.0	7	0.7	5.1	
Chain guide and swingarm	M6 × 1.0	7	0.7	5.2	
Bolt (at swingarm end)	M6 × 1.0	3	0.3	2.2	
Front wheel/Rear wheel:					
Front wheel axle and nut	M14 × 1.5	110	11.0	80	
Rear wheel axle and nut	M16 × 1.5	90	9.0	65	
Front axle holder	M6 × 1.0	8	0.8	5.8	
Brake caliper (Front) and front fork	M10 × 1.25	35	3.5	25	
Brake caliper (Rear) and bracket	M10 × 1.25	35	3.5	25	
Bracket and swingarm	M10 × 1.25	45	4.5	32	



Model	XT600Z(U)				Remarks
Part to be tightened	Thread size	Tightening torque			
		Nm	m•kg	ft•lb	
Footrest/Pedal/Stand:					
Sidestand and frame	M10×1.25	40	4.0	29	
Rear brake switch and frame	M6 ×1.0	4	0.4	2.9	
Footrest (For rider) and frame	M10×1.25	45	4.5	32	
Footrest (For passenger) and frame	M8 ×1.25	20	2.0	14	
Master cylinder (Rear brake) and frame	M8 ×1.25	20	2.0	14	
Reservoir tank (Rear brake) and frame	M6 ×1.0	4	0.4	2.9	
Tank/Seat/Cover/Fender:					
License bracket	M6 ×1.0	5	0.5	3.6	
Rear reflector	M5 ×0.8	4	0.4	2.9	
Oil tank and oil hose	M6 ×1.0	10	1.0	7.2	
Drain bolt (Oil tank)	M8 ×1.25	18	1.8	13	
Special bolt (Oil tank)	M12×1.25	20	2.0	14	
Helmet holder and frame	M6 ×1.0	4	0.4	2.9	
Seat and frame	M6 ×1.0	10	1.0	7.2	
Front fender and lower bracket	M6 ×1.0	7	0.7	5.1	
Rear fender	M6 ×1.0	7	0.7	5.1	
Battery box and frame	M6 ×1.0	7	0.7	5.1	
Fuel tank stay and frame	M6 ×1.0	7	0.7	5.1	
Fuel tank and frame	M6 ×1.0	7	0.7	5.1	
Fuel pump and frame	M5 ×0.8	5	0.5	3.6	
Fuel pump and clamp	M6 ×1.0	7	0.7	5.1	
Oil tank and frame	M8 ×1.25	10	1.0	7.2	
Oil cooler and frame	M6 ×1.0	7	0.7	5.1	
CDI unit and mud guard	M6 ×1.0	4	0.4	2.9	
License bracket and taillight	M6 ×1.0	7	0.7	5.1	
Regulator and battery box	M6 ×1.0	7	0.7	5.1	
Regulator and battery box	M16×1.25	35	3.5	25	
Regulator and battery box	M12×1.25	24	2.4	17	

NOTE:

1. First, tighten the ring nut approximately 38 Nm (3.8 m•kg, 27 ft•lb) by using the torque wrench, then loosen the ring nut one turn.
2. Retighten the ring nut to specification.



ELECTRICAL

Model	XT600Z(U)
Voltage:	12V
Ignition System: Ignition Timing (B.T.D.C.) Advanced Timing (B.T.D.C.) Advancer Type	12° at 1,200 r/min 36° at 6,000 r/min Electrical Type
<p>The graph plots Ignition Timing (B.T.D.C.) in degrees on the y-axis (0° to 40°) against Engine Speed in 10³ r/min on the x-axis (0 to 10). The timing starts at 5° for speeds up to 0.5 x 10³ r/min, jumps to 12° at 1.2 x 10³ r/min, then increases linearly to 36° at 4 x 10³ r/min, and remains constant at 36° for speeds up to 9 x 10³ r/min.</p>	
C.D.I.: Magneto Model/Manufacturer Pickup Coil Resistance (Color) Source Coil Resistance (Color) C.D.I. Unit Model/Manufacturer	VCD92/NIPPON DENSO 92 ~ 138Ω at 20°C (68°F) (Blue/Yellow—Black/Yellow) 92 ~ 138Ω at 20°C (68°F) (Green/White—Black/Yellow) 112 ~ 132Ω at 20°C (68°F) (Brown—Red) QAB52-50/NIPPON DENSO
Ignition Coil: Model/Manufacturer Minimum Spark Gap Primary Coil Resistance Secondary Coil Resistance	J0138-50/NIPPON DENSO 6.0 mm (0.24 in) 0.15 ~ 0.21Ω at 20°C (68°F) 3.8 ~ 5.8 kΩ at 20°C (68°F)



Model	XT600Z(U)
Spark Plug Cap: Type Resistance	Resin type 8 ~ 12k Ω at 20°C (68°F)
Charging System: Type Model/Manufacturer Output	A.C. magneto generator VCD92/NIPPONDENSO 14V 12A at 5,000 r/min
<p style="text-align: center;">Charging Current (A)</p> <p style="text-align: center;">Engine speed ($\times 10^3$ r/min)</p>	
Charging Coil Resistance (Color)	0.7 ~ 1.1 Ω at 20°C (68°F) (W—W)
Voltage Regulator/Rectifier: Model/Manufacturer Voltage Regulator: Type No Load Regulated Voltage Rectifier: Capacity Withstand Voltage	SH569/SHINDENGEN Semi conductor-short circuit type 14.3 ~ 15.3V 25A 240V
Battery: Specific Gravity	1.280
Starter Motor: Model/Manufacturer Output Brush Overall Length < Limit > Brush Spring Pressure < Limit > Commutator Dia. < Limit > Mica Undercut	SM13/MITSUBA 0.8kW 12 mm (0.47 in) < 5 mm (0.20 in) > 680 ~ 920 g (24.0 ~ 32.4 oz) < 520 g (13.6 oz) > 28 mm (1.10 in) < 27 mm (1.06 in) > 0.7 mm (0.028 in)
Starter Switch: Model/Manufacturer Amperage Rating	I26-22011-D000/HONDA LOCK 100A

MAINTENANCE SPECIFICATIONS

SPEC



C


Model	XT600Z(U)
Horn: Type Quantity Model/Manufacturer Maximum Amperage	Plane type 1 pc. YF-12/NIKKO 2.5A
Flasher Relay: Type Model/Manufacturer Self Cancelling Device Flasher Frequency Wattage	Condenser type FZ249SD/NIPPON DENSO FJ245EF/NIPPON DENSO.....(D) No 75~95 cycles/min 21W×2+3.4W
Circuit Breaker: Type Amperage for Individual	Fuse 20A



GENERAL TORQUE SPECIFICATIONS

This chart specifies torque for standard fasteners with standard I.S.O. pitch threads. Torque specifications for special components or assemblies are included in the applicable sections of this book. To avoid warpage, tighten multi-fastener assemblies in a crisscross fashion, in progressive stages, until full torque is reached. Unless otherwise specified, torque specifications call for clean, dry threads. Components should be at room temperature.

A (Nut)	B (Bolt)	General torque specifications		
		Nm	m•kg	ft•lb
10 mm	6 mm	6	0.6	4.3
12 mm	8 mm	15	1.5	11
14 mm	10 mm	30	3.0	22
17 mm	12 mm	55	5.5	40
19 mm	14 mm	85	8.5	61
22 mm	16 mm	130	13.0	94



A: Distance across flats
B: Outside thread diameter

DEFINITION OF UNITS

Unit	Read	Definition	Measure
mm	millimeter	10^{-3} meter	Length
cm	centimeter	10^{-2} meter	Length
kg	kilogram	10^3 gram	Weight
N	Newton	$1 \text{ kg} \times \text{m}/\text{sec}^2$	Force
Nm	Newton meter	$\text{N} \times \text{m}$	Torque
m•kg	Meter kilogram	$\text{m} \times \text{kg}$	Torque
Pa	Pascal	N/m^2	Pressure
N/mm	Newton per millimeter	N/mm	Spring rate
L	Liter	—	Volume or capacity
cm^3	Cubic centimeter	—	Volume or capacity
r/min	Rotation per minute	—	Engine speed

LUBRICATION POINTS AND LUBRICANT TYPE

SPEC



LUBRICATION POINTS AND LUBRICANT TYPE ENGINE

Lubrication Points (Part name)	Lubricant Type
Oil seal lips (All)	
Bearing retainer	
Crank Pin	
Connecting rod (Big end)	
Piston and piston ring	
Boss (Balancer drive gear)	
Piston pin	
Valve stem and valve guide	
Oil seal (Valve stem end)	
Rocker arm shaft and rocker arm	
Cam and bearing (Camshaft)	
Rotor and rotor housing (Oil pump)	
Push rod	
Primary driven gear and main axle	
Sliding gear (Transmission)	
Free movement gear (Transmission)	
Shift fork and guide bar	
Shift cam and bearing (Shift cam)	
Shift shaft	
Crankcase mating surfaces	Yamaha Bond No. 1215
Mating surfaces (Cylinder head and cylinder head cover)	Yamaha Bond No. 1215




CHASSIS

Lubrication Points (Part name)	Lubricant Type
Gear unit (Speedometer)	LS
Oil seal lips (All)	LS
Wheel axle (Front wheel and rear wheel)	LS
Rear wheel hub and clutch hub	LS
Bush (Swingarm) and thrust cover	LS
Pivot shaft (Swingarm)	LS
Bushes (Rear shock absorber)	LS
Bushes (Relay arm and connecting rod)	LS
Bearings (Relay arm and connecting rod)	LS
Pivoting points (Brake pedal and change pedal)	LS
Bearings (Steering head)	LS
Right handlebar end	LS
Pivoting points (Brake lever and clutch lever)	LS
Clutch cable end	LS
Pivoting point (Sidestand)	LS
Bushes (Chain tensioner)	LS
Grease nipple (Swingarm)	LS
Grease nipple (Relay arm)	LS
Grease nipple (Connecting arm)	LS


LUBRICATION DIAGRAM

- ① Oil tank
- ② Oil strainer
- ③ Oil pump





- ① Camshaft
- ② Oil cleaner
- ③ Oil pump




LUBRICATION DIAGRAM

SPEC




- ① Oil cleaner
- ② Crank pin
- ③ Main axle
- ④ Drive axle






- ① Oil cleaner
- ② Oil pump
- ③ Shift cam
- ④ Oil strainer






CABLE ROUTING

- | | |
|------------------------------|---------------------------------|
| ① Flasher light lead (Right) | ⑫ Brake hose |
| ② Clamp | ⑬ Throttle cable 2 |
| ③ Tachometer cable | ⑭ Throttle cable 1 |
| ④ Meter lead | ⑮ Cable guide |
| ⑤ Flasher light lead (Left) | ⑯ Clutch cable |
| ⑥ Speedometer cable | ⑰ Handlebar switch lead (Left) |
| ⑦ Starter cable | ⑱ Handlebar switch lead (Right) |
| ⑧ Headlight lead | ⑲ Stop switch lead |
| ⑨ Clutch switch lead | ⑳ Fuel hose |
| ⑩ Main switch lead | ㉑ Wireharness |
| ⑪ Band | ㉒ Fuel pump |




- | | | |
|---------------------|-------------------------|------------------------------|
| ① Clutch cable | ⑩ Throttle cable 2 | ⑲ Breather hose (Carburetor) |
| ② Speedometer cable | ⑪ Starter switch ass'y | ⑳ Overflow hose (Carburetor) |
| ③ Brake hose | ⑫ Battery lead + | ㉑ Breather hose (Battery) |
| ④ Clamp | ⑬ Battery lead - | ㉒ Oil hose |
| ⑤ Band | ⑭ Fuse | ㉓ Breather hose (Crankcase) |
| ⑥ Throttle cable | ⑮ Battery | ㉔ CDI magneto lead |
| ⑦ Cable guide | ⑯ Rectifier/Regulator | ㉕ Starter cable |
| ⑧ Ignition coil | ⑰ Flasher relay | ㉖ Wireharness |
| ⑨ Throttle cable 1 | ⑱ Sidestand switch lead | |



CABLE ROUTING




- ① Throttle cable 1
- ② Throttle cable 2
- ③ Stop switch lead
- ④ Handlebar switch lead (Right)
- ⑤ Cable guide
- ⑥ Clamp
- ⑦ Main switch lead
- ⑧ Wireharness
- ⑨ Tachometer cable
- ⑩ Fuel hose
- ⑪ Stop switch lead
- ⑫ Holder
- ⑬ Breather hose (Oil tank)
- ⑭ Band
- ⑮ Breather hose





- ① Clamp
- ② Band
- ③ Rectifier/Regulator
- ④ Sidestand switch relay
- ⑤ Wireharness
- ⑥ Flasher light lead (Left)
- ⑦ Flasher light lead (Right)
- ⑧ Battery lead (+)
- ⑨ Battery lead (-)
- ⑩ Battery





PERIODIC INSPECTION AND ADJUSTMENT

INTRODUCTION

This chapter includes all information necessary to perform recommended inspections and adjustments. These preventive maintenance procedures, if followed, will ensure more reliable vehicle operation and a longer service life. The need for costly overhaul work will be greatly reduced. This information applies to vehicles already in service as well as new vehicles that are being prepared for sale. All service technicians should be familiar with this entire chapter.

PERIODIC MAINTENANCE/LUBRICATION INTERVALS

Unit: km (mi)

ITEM	REMARKS	BREAK-IN 1,000 (600)	EVERY	
			6,000 (4,000) or 6 months	12,000 (8,000) or 12 months
Valve clearance	Check/Adjust valve clearance.	○	○	○
Spark plug	Check/Clean/Replace if necessary.	○	○	○
Air filter	Clean. Replace if necessary.		○	○
Carburetor	Check/Adjust idle speed, starter operation.	○	○	○
Fuel line	Check fuel hose for cracks or damage.		○	○
Engine oil	Replace (Warm engine before draining).	○	○	○
Engine oil filter/ Oil strainer	Replace filter element and clean oil strainer.	○	○	○
Brake	Check operation/fluid leakage/See NOTE./ Adjust if necessary.		○	○
Clutch	Check operation/Adjust if necessary.		○	○
Swingarm pivot/ Swingarm	Check swingarm assembly for looseness. Clean and lube.***	CHECK	○	○
Wheels	Check balance/damage/runout/spoke tightness.		○	○
Wheel bearings	Check bearings assembly for looseness/damage. Replace if damaged.		○	○
Steering bearing	Check bearings assembly for looseness. Moderately repack every 24,000 (16,000) or 24 months.***	CHECK		CHECK
Front forks	Check operation/oil leakage.		○	○
Rear shock absorber	Check operation/oil leakage.		○	○
Drive chain	Check and adjust slack/alignment/clean/lube.		EVERY 500 (300)	
Fittings/Fasteners	Check all chassis fittings and fasteners.	○	○	○
Sidestand switch (For Europe)	Check operation. Clean or replace if necessary.	○	○	○
Battery	Check specific gravity. Check breather pipe for proper operation.		○	○

***: Lithium base grease



PERIODIC MAINTENANCE/ LUBRICATION INTERVALS

INSP
ADJ



NOTE:


Brake system:

1. When disassembling the master cylinder or caliper cylinder, replace the brake fluid. Normally check the brake fluid level and add the fluid as required.
 2. We recommended that, on the inner parts of the master cylinder and caliper cylinder, replace the oil seals every two years.
 3. We recommended that, replace the brake hoses every four years, or if cracked or damaged.
-




SEAT, FUEL TANK AND COVER REMOVAL

1. Remove:
 - Seat




2. Remove:
 - Side cover



3. Turn the fuel cock levers (Left and right) to "OFF".

4. Disconnect:
 - Fuel hoses (Left and right) ①




- A** Left
- B** Right

5. Remove:
 - Fuel tank



- A** Left
- B** Right



INSTALLATION

Reverse the "REMOVAL" procedure. Note the following points.

1. Install:
 - Side cover
 - Seat
 - Fuel tank





Bolt (Side Cover):
7 Nm (0.7m•kg, 5.1 ft•lb)
Bolt (Seat):
10 Nm (1.0m•kg, 7.2 ft•lb)
Bolt (Cowl and Fuel Tank)
4 Nm (0.4m•kg, 2.9 ft•lb)

ENGINE

ENGINE OIL LEVEL INSPECTION

1. Inspect:
 - Engine oil level
Oil level low→Add sufficient oil.



Engine oil level inspection steps:

- Place the motorcycle on a level place.

NOTE: _____
Be sure the motorcycle is positioned straight up and on both wheels.

- Remove the side cover (Right).
- Remove the oil tank cap ① completely out, and then just rest the cap in the hole.

NOTE: _____
When checking, do not screw the oil level gauge ① into the oil tank. Insert the gauge lightly. For accuracy, check with the motorcycle held upright.

- Pull up the cap, and inspect the oil level whether or not it is between maximum ② and minimum level ③.
Sufficient oil→Start the engine.
Insufficient oil→Add the oil up to the minimum level and start the engine.

CAUTION: _____

When the oil tank is empty, never start the engine.

- Warm up until the oil temperature rises to approximately 60°C (140°F).
- Idle the engine more than 10 seconds while keeping the motorcycle upright, and stop the engine.
- Inspect the oil level with the oil tank cap, and apply the engine oil to the maximum level.



WARNING: _____

Never attempt to remove the oil tank cap just after high speed operation. The heated oil could spout out, causing danger. Wait until the oil cools down to approximately 60°C (140°F).

ENGINE OIL REPLACEMENT

CAUTION: _____

The replacement of engine oil should be made through the drain holes in the crankcase and the oil tank. To drain the oil, never disconnect the oil hose at the engine side, or engine damage may result.




Engine Oil Replacement (Without Oil Filter)

1. Start the engine and stop after a few minutes of warming up.
2. Remove:
 - Engine guard ①
 - Side cover (Right)
3. Place the oil receiver under the engine.
4. Remove:
 - Oil tank cap
 - Drain plug (Crankcase) ①
 - Air bleed screw ②
 - Filter cover screw ③Drain the engine oil.

NOTE: _____

The oil filter cover is secured by three screws. The lower one should be removed so that the filter cavity will drain.



5. Loosen:
- Drain plug (Oil tank) ①
 - Special bolt ②

NOTE:

- Loosen the special bolt as far as its groove.
- Before removing the drain bolt, loosen out the special bolt to a sufficient length that will protect the frame from the dripping oil.

6. Remove:
- Drain plug (Oil tank)
Drain the engine oil.

7. Inspect:
- Gasket (Drain plug-Crankcase)
 - Gasket (Drain plug-Oil tank)
Damage → Replace.

8. Tighten:
- Components in above list (Steps "6~2")

**Drain Plug (Crankcase):**

30 Nm (3.0 m•kg, 22 ft•lb)

Drain Plug (Oil Tank):

18 Nm (1.8 m•kg, 13 ft•lb)

Special Bolt (Oil Tank):

20 Nm (2.0 m•kg, 14 ft•lb)

Screw (Filter Cover):

10 Nm (1.0 m•kg, 7.2 ft•lb)

Air Bleed Screw:

5 Nm (0.5 m•kg, 3.6 ft•lb)

9. Fill:
- Oil tank

**Recommended Oil:**

SAE 20W40 Type SE Motor Oil


Periodic Oil Change:

1,9 L (1,7 Imp qt, 2,0 US qt)

CAUTION:

Do not allow foreign material to enter the oil tank.

10. Inspect:
- Oil leaks
 - Oil level
 - Oil pressure




Engine Oil Replacement (With Oil Filter)

1. Start the engine and stop after a few minutes of warm up.

2. Remove:


- Engine guard ①
- Side cover (Right)

3. Place the oil receiver under the engine.



4. Remove:

- Oil tank cap
 - Drain plug (Crankcase) ①
 - Oil filter cover ②
 - Oil filter
- Drain the engine oil.





5. Loosen:

- Drain plug (Oil tank) ①
- Special bolt ②

NOTE:

- Loosen the special bolt as far as its groove.
- When the drain plug is removed, the oil flows out. Before removing the drain bolt, loosen out the special bolt to a sufficient length that will protect the frame from the dripping oil.



6. Remove:

- Drain plug (Oil tank)
Drain the engine oil.

7. Inspect:


- Gasket (Drain plug-Crankcase)
- Gasket (Drain plug-Oil tank)
- O-rings ①
Damage → Replace.

8. Install:

- Oil filter (New) ①
- Oil filter cover


9. Tighten:

- Components in above list (Step "6~2").

	Drain Plug (Crankcase): 30 Nm (3.0 m•kg, 22 ft•lb) Drain Plug (Oil Tank) 18 Nm (1.8 m•kg, 13 ft•lb) Special Bolt (Oil Tank): 24 Nm (2.4 m•kg, 17 ft•lb) Bolts (Filter Cover): 10 Nm (1.0 m•kg, 7.2 ft•lb) Air Bleed Screw: 5 Nm (0.5 m•kg, 3.6 ft•lb)
---	---

10. Fill:

- Oil tank

	Recommended Oil: SAE 20W40 Type SE Moter Oil With Oil Filter Replacement: 2.0 L (1.8 Imp•qt, 2.1 US qt)
---	--

CAUTION:


Do not allow foreign materal to enter the oil tank.

11. Install:

- Oil tank cap

12. Inspect:

- Oil leaks
- Oil level
- Oil pressure





CLUTCH ADJUSTMENT

Free Play Adjustment

1. Remove:
 - Brush guard (Left)
2. Loosen:
 - Locknuts ①
3. Adjust:
 - Free play ②

Turn the adjusters ② until the free play is within the specified limits.




	Free Play ②
	2~3 mm (0.08~0.12 in)

4. Tighten:
 - Locknuts

NOTE:



The above procedure provides for maximum cable free play to allow for proper clutch actuating mechanism adjustment.



Mechanism Adjustment

1. Loosen:
 - Cable length adjuster locknuts (Fully)
2. Tighten:
 - Cable length adjusters (Until tight)
3. Drain:
 - Engine oil

Refer to the "ENGINE OIL REPLACEMENT" section.
4. Remove:
 - Engine guard
 - Brake pedal assembly
 - Crankcase cover (Right)
 - Starter motor bracket



5. Loosen:
 - Locknut ①
6. Push the push lever toward the front of the engine with your finger until it stops.

② Adjuster

7. Adjust:
 - Free play
With the push lever in this position, turn the adjuster either in or out until the push lever mark ② and crankcase match mark ① are aligned.
8. Tighten:
 - Locknut



Locknut:

8 Nm (0.8 m•kg, 5.8 ft•lb)

9. Install:
 - Crankcase cover (Right)




Screw (Crankcase Cover):

10 Nm (1.0 m•kg, 7.2 ft•lb)


10. Fill:
 - Oil tank
 - Crankcase
Refer to the "ENGINE OIL REPLACEMENT" section.

11. Adjust:
 - Clutch cable free play
Refer to the "Cable Free Play Adjustment" section.



AIR FILTER CLEANING


1. Remove:
 - Seat
 - Air filter case cover ①



2. Remove:
 - Element holder ①
 - Air filter element ②

CAUTION: _____

The engine should never be run without the air filter element; excessive piston and/or cylinder wear may result.



3. Remove:
 - Filter element guide ①

4. Clean:
 - Air filter element

Cleaning steps:

- Wash the element gently, but thoroughly, in solvent.

WARNING: _____

Never use low flash point solvents such as gasoline to clean the air filter element. Such solvent may lead to a fire or explosion.

- Squeeze the excess solvent out of the filter and let dry.

CAUTION: _____


Do not twist the filter element when squeezing the filter element.



5. Inspect:
 - Air filter element
Damage → Replace.
6. Pour a small quantity of foam-air-filter oil or Air cooled 2-cycle engine oil onto the filter element and work thoroughly into the porous foam material.

NOTE: _____


In order to function properly, the element must be damp with oil at all times, but not dripping with oil.



7. Install:
 - Components in above list (Step "3~1")

NOTE: _____

Fit the filter element on the filter case and coat the sealing edge of the element with light grease to provide an airtight seal.




FUEL LINE INSPECTION

1. Inspect:
 - Fuel hoses (Fuel cocks-Fuel pump) ①
 - Fuel hose (Fuel pump-Carburetor) ②Cracks/Damage → Replace.
Clogs → Clean.

ENGINE OIL TANK STRAINER CLEANING

CAUTION:

Never fail to bleed the hose of air when removing the oil hose (Oil tank-crankcase), disassembling the engine, and cleaning the engine oil tank strainer.




Removal

1. Remove:
 - Engine guard
 - Side cover (Right)
 - Oil tank cap
2. Loosen:
 - Drain plug (Oil tank) ①
 - Special bolt ②


NOTE:

- Loosen the special bolt as far as its groove.
- Before removing the drain bolt, loosen out the special bolt to a sufficient length that will protect the frame from the dripping oil.

3. Place the oil receiver under the special bolt end.



4. Remove:
 - Drain bolt (Oil tank)
Drain the engine oil.
5. Disconnect:
 - Oil hose (Upper) ①
 - Oil hose (Lower) ②
6. Remove:
 - Bolts (Oil tank) ③
 - Oil tank ④
 - Oil strainer ⑤




Cleaning

1. Clean:
 - Oil strainer ①
Blow out the oil strainer with compressed air.
 - Oil tank
Clean it with solvent.

NOTE: _____

After cleaning the inside of oil tank, remove the solvent thoroughly.




2. Inspect:
 - O-rings ①
Damage → Replace.

Installation

When installing the side covers, reverse the removal procedure.


Note the following points.

1. Install:
 - Oil tank
 - Oil strainer
 - O-rings




CAUTION: _____


- Be sure to provide clearance between the oil tank rear ① and the frame ②.
- Make sure that the oil tank bottom ③ is in contact with the damper ④.



	<p>Bolts (Oil Tank): 10 Nm (1.0 m•kg, 7.2 ft•lb)</p>
---	---

2. Connect:
 - Oil hose (Upper)
 - Oil hose (Lower)

	<p>Nut (Oil Hose-Upper): 35 Nm (3.5 m•kg, 25 ft•lb)</p> <p>Bolts (Oil Hose-Lower): 10 Nm (1.0 m•kg, 7.2 ft•lb)</p>
---	--

3. Tighten:
- Special bolt
 - Drain bolt (Oil tank)

	Drain Plug (Oil Tank):
	18 Nm (1.8 m•kg, 13 ft•lb)
	Special Bolt (Oil Tank)
	20 Nm (2.0 m•kg, 14 ft•lb)



4. Bleed:
- Air bubbles (Oil hose)


Oil hose (Oil tank-Crankcase) air bleeding steps.

- Put the engine oil into the oil tank.

CAUTION:

Put the engine oil more than minimum level.

- Place the motorcycle on level place.
- Disconnect the oil hose (Crankcase side) ①.
- Keep the engine oil running out until air bubbles disappear.
- When air bubbles are expelled completely, connect the oil hose.


	Bolts (Oil Hose):
	10 Nm (1.0 m•kg, 7.2 ft•lb)

- Remove the air bleed screw ②.
- Start the engine and race it approximately 10 times in a speed range of idling to 3,000 r/min.
- Inspect the engine oil condition of the bleed hole. If the engine oil flows out, the oil pressure is good.



CAUTION:

If no oil comes out after a lapse of one minute, turn off the engine immediately so it will not seize.

- Tighten the air bleed screw.

	Air Bleed Screw:
	5 Nm (0.5 m•kg, 3.6 ft•lb)

- Add the engine oil and check the engine oil level.
Refer to "ENGINE OIL LEVEL INSPECTION" section.




ELECTRICAL
BATTERY INSPECTION

1. Remove:
 - Seat
 - Band ①
 - Battery ②

NOTE: _____
Disconnect the negative lead first, and then disconnect the positive lead.

2. Check:
 - Fluid level
Incorrect → Refill.
Fluid level should be between upper ① and lower ② level marks.

CAUTION: _____
Normal tap water contains minerals which are harmful to a battery; therefore, refill only with distilled water.



3. Inspect:
 - Battery fluid specific gravity
Out of specification → Charge.

Charging Current:
1.2 Amps/10 Hrs.
Specific Gravity:
1.280 at 20°C (68°F)

WARNING: _____
Battery electrolyte is dangerous; it contains sulfuric acid and therefore is poisonous and highly caustic.

- Always follow these preventive measures:
- Avoid bodily contact with electrolyte as it can cause severe burns or permanent eye injury.
 - Wear protective eye gear when handling or working near batteries.
- Antidote (EXTERNAL):**
- SKIN — Flush with water.



•EYES – Flush with water for 15 minutes and get immediate medical attention.

Antidote (INTERNAL):

•Drink large quantities of water or milk (follow with milk of magnesia) beaten egg, or vegetable oil. Get immediate medical attention.

Batteries also generate explosive hydrogen gas, therefore you should always follow these preventive measures:

- Charge batteries in a well-ventilated area.
- Keep batteries away from fire, sparks, or open flames (e.g., welding equipment, lighted cigarettes, etc.)
- DO NOT SMOKE when charging or handling batteries.

KEEP BATTERIES AND ELECTROLYTE OUT OF REACH OF CHILDREN.

4. Inspect:


- Battery breather hose
Obstruction → Remove.
Damage → Replace.

5. Install:

- Battery

NOTE: _____

Connect the positive lead first, and then connect the negative lead.




6. Connect/Inspect:

- Battery breather hose ①
Be sure the hose is properly attached and routed.

- ② Pass through guide.
- ③ Pass inside rear arm.


CAUTION: _____

When inspecting the battery, be sure the breather hose is routed correctly. If the breather hose touches the frame or exits in such a way as to cause battery electrolyte or gas to exit onto the frame, structural and cosmetic damage to the motorcycle can occur.




HEADLIGHT BULB REPLACEMENT

1. Disconnect:
 - Headlight leads ①
2. Remove:
 - Bulb cover ②



3. Remove:
 - Defective bulb ①
Turn the bulb holder counterclockwise to release bulb.



- Defective bulb ②
Remove the bulb holder and defective bulb.

WARNING:

Keep flammable products or your hands away from the bulb while it is on, it will be hot. Do not touch the bulb until it cools down.


4. Install:

- Bulb (New)
Secure the new bulb with the bulb holder.

CAUTION:

Avoid touching glass part of bulb. Also keep it free from oil otherwise, transparency of glass, bulb life and illuminous flux will be adversely affected. If oil gets on bulb, clean it with a cloth moistened thoroughly with alcohol or lacquer thinner.


HEADLIGHT BEAM ADJUSTMENT/ HEADLIGHT BEAM VARIATION



HEADLIGHT BEAM ADJUSTMENT

- Adjust
 - Headlight beam (Vertical)

To raise the beam	Turn the adjuster ① clockwise.
To lower the beam	Turn the adjuster ① counterclockwise.



- Adjust
 - Headlight beam (Horizontal)
(Left)

To right the beam	Turn the adjuster ② clockwise.
To left the beam	Turn the adjuster ② counterclockwise.

(Right)

To right the beam	Turn the adjuster ③ Counterclockwise.
To left the beam	Turn the adjuster ③ clockwise.

Headlight beam variation

※ LIGHT "ON"
○ LIGHT "OFF"

	Lighting	Bulb to be used	Destination
HI	☀ ○ A		Germany Greece Belgium Portugal Sweden Spain France
LO	○ ☀ A		
HI	A ☀ ☀ A		Oceania and S. Africa England Denmark Italy
LO	A ☀ ☀ A		
HI	☀ ☀ A		Finland Holland
LO	○ ☀ A		
HI	☀ A		Switzerland Norway
LO	☀ A		

A ... Auxiliary light



ENGINE OVERHAUL

The model XT600Z features a new starter motor, improving the starting performance.




As a result, the conventional kick start system has been eliminated.

DISASSEMBLY

NOTE:


The following parts can be overhauled without dismounting the engine.

- Starter motor
- CDI magneto
- Starter gears




STARTER MOTOR


1. Loosen:
 - Bolt (Muffler band) ①
 - Bolt (Muffler) ②
2. Remove:
 - Exhaust pipe ③
3. Remove:
 - Engine oil delivery pipe ①
4. Disconnect:
 - Ground lead (Engine) ①
 - Starter motor lead ②




5. Remove:
 - Bolts (Case cover)
6. Loosen:
 - Adjuster (Clutch cable)
7. Disconnect:
 - Clutch cable ①
8. Remove:
 - Case cover ② (Starter idle gear)




9. Remove:
 - Gasket ①
 - Dowel pin ②
 - Thrust washer ③



10. Remove:
 - Starter idle gear ① (Primary)
 - Bearing ②
 - Idle gear axle ③ (Primary)
 - Circlip ④
 - Drive gear ⑤ (Starter motor)




11. Remove:
 - Starter motor ①




MAGNETO ROTOR AND STARTER GEARS


1. Remove:
 - Engine guard ①
 - Change pedal
 - Cover (Drive sprocket)
2. Drain:
 - Engine oil
 Refer to "ENGINE OIL REPLACEMENT" section.




3. Disconnect:
- CDI magneto leads ①




4. Disconnect:
- Neutral switch lead ①
5. Remove:
- Crankcase cover ② (Left)



6. Remove:
- Gasket ① (Crankcase cover)
 - Dowel pins ②



7. Remove:
- Idle gear axle ① (Secondary)
 - Bearing ②
 - Starter idle gear ③ (Secondary)




8. Remove:
- Nut ① (Magneto rotor)
 - Plain washer
- Use the Rotor Holder ② to lock the magneto rotor.




Rotor Holder:
90890-01701


CAUTION:

Do not allow the special tool to touch the projections ③ on the magneto rotor.




9. Remove:
- Magneto rotor ①
 - Woodruff key
- Use the Rotor Puller ②

	<p>Rotor Puller: 90890-01362</p>
---	---




10. Remove:
- Thrust washer ①
 - Bearings ②
 - Starter wheel gear ③
 - (from magneto rotor ④)

NOTE: For removal of the starter wheel gear, turn the gear counterclockwise as you pull it out.




**INSPECTION AND REPAIR
STARTER DRIVES**

1. Inspect:
- Drive gear ① (Starter motor)
 - Starter idle gear ②
 - Starter idle gear ③ (Secondary)
 - Starter wheel gear ④
- Wear/Cracks/Damage → Replace.




2. Inspect:
- Bearing ① (Primary-Idle gear)
- Pitting/Damage → Replace.



3. Inspect:

- Idle gear axle ① (Primary)
 - Bearing ② (Primary-Idle gear)
 - Idle gear axle ③ (Secondary)
 - Bearing ④ (Secondary-Idle gear)
- Wear/Pitting/Damage → Replace.




4. Check:

- Starter clutch (Roller operation)
- Push the roller in arrow direction.
Unsmooth operation → Replace starter clutch.


5. Check:

- Pins (Starter clutch)
- Pitting/Wear/Damage → Replace starter clutch.



6. Inspect:

- Contacting surfaces (Starter wheel gear)
- Pitting/Wear/Damage → Replace.





7. Check:

- Starter clutch operation

Clutch operation checking steps:

- Install the starter wheel gear to the starter clutch, and hold the starter clutch.
- When turning the wheel gear clockwise, the starter clutch and the wheel gear should be engaged.
If not, the starter clutch is faulty. Replace it.
- When turning the wheel gear counterclockwise, the wheel gear should turn freely.
If not, the starter clutch is faulty. Replace it.






8. Inspect:


- Engine oil delivery pipe ①
 - Cracks/Damage → Replace.
 - Clog → Blow out with compressed air.
- Union bolt ②
 - Cracks/Damage → Replace.
 - Clog → Blow out with compressed air.
- Copper washer ③
 - Damage → Replace.

STARTER DRIVES

- ① Starter motor drive gear
- ② Primary starter idle gear
- ③ Bearing
- ④ Primary idle gear axle
- ⑤ Secondary starter idle gear
- ⑥ Secondary idle gear axle
- ⑦ Bearing
- ⑧ Starter wheel gear
- ⑨ Starter clutch
- ⑩ Bearings
- ⑪ CDI magneto

A AFTER INSTALLING THE STARTER CLUTCH, CALK THE BOLT END, AS SHOWN.







**ASSEMBLY AND ADJUSTMENT
STARTER GEARS AND MAGNETO ROTOR**

1. Install:
 - Thrust washer ①
(to crankshaft)

NOTE: _____
Apply the engine oil to the thrust washer.




2. Clean:
 - Starter clutch pin
3. Lubricate:
 - Starter clutch pin

 **Molybdenum Disulfide Oil**




4. Install:
 - Starter wheel gear ①
(to the magneto rotor ②)
 - Bearings ③

NOTE: _____
• For installation of the starter wheel gear, turn the gear counterclockwise as you push it in.
• Apply the engine oil to the bearings.



5. Install:
 - Woodruff key ①
 - Magneto rotor ②
(with starter wheel gear)
 - Plain washer ③
 - Nut ④ (Magneto rotor)

NOTE: _____
• When installing the CDI magneto, make sure the woodruff key is properly seated in the key way of the crankshaft.
• Apply a light coating of lithium soap base grease to the tapered portion of the crankshaft end.



6. Tighten:

- Nut ① (Magneto rotor)
- Use the Rotor Holder ② to lock the magneto rotor.




Rotor Holder:
90890-01701

CAUTION:

Do not allow the special tool to touch the projections ③ on the magneto rotor.



Nut (Magneto Rotor):
120 Nm (12.0 m·kg, 85 ft·lb)




7. Install:

- Starter idle gear ① (Secondary)
- Bearing ②
- Idle gear axle ③ (Secondary)


NOTE:

Apply the engine oil to the bearing and idle gear axle.



8. Install:

- Dowel pins ①
- Gasket ② (New)



9. Install:


- Crankcase cover ① (Left)



Bolt (Crankcase Cover):
10 Nm (1.0 m·kg, 7.2 ft·lb)

NOTE:

- Tighten the bolts in stage, using a crisscross pattern.
- Be careful not to pinch the neutral lead.




10. Connect:
 - Neutral switch lead ①
 - CDI magneto leads ②
11. Install:
 - Cover (Drive sprocket)
 - Change pedal

	Bolt (Cover):
	10 Nm (1.0 m•kg, 7.2 ft•lb)
	Bolt (Change Pedal):
	10 Nm (1.0 m•kg, 7.2 ft•lb)


12. Apply
 - Engine oil
 Refer to "ENGINE OIL REPLACEMENT" section.

	Oil Quantity:
	2.4 L (2.1 Imp qt, 2.5 US qt)



13. Install:
 - Engine guard ①

	Bolt (Engine Guard):
	10 Nm (1.0 m•kg, 7.2 ft•lb)



STARTER MOTOR


1. Lubricate:
 - O-ring (Starter motor)


	Lithium Soap Base Grease
--	---------------------------------

2. Install:
 - Starter motor
 Temporarily tighten the bolts.

3. Install:
 - Idle gear axle ① (Primary)
 - Bearing ②
 - Starter idle gear ③ (Primary)
 - Drive gear ④ (Starter motor)
 - Circlip ⑤


NOTE: _____
 Apply the engine oil to the idle gear axle and bearing.







4. Install:
- Thrust washer ①
 - Dowel pin ②
 - Gasket ③

NOTE: _____
Apply the molybdenum disulfide oil to the thrust washer.




5. Install:
• Case cover ① (Starter idle gear)
6. Connect:
• Clutch cable ②
7. Tighten:
• Bolts (Case cover)


 **Bolt (Case Cover)**
10 Nm (1.0 m•kg, 7.2 ft•lb)




8. Connect:
• Starter motor lead ①
- Ground lead ② (Engine)


9. Tighten:
• Bolts ③ (Starter motor)

 **Bolt (Starter Motor)**
10 Nm (1.0 m•kg, 7.2 ft•lb)




10. Install:
• Engine oil delivery pipe ①

 **Union Bolt (Delivery Pipe):**
18 Nm (1.8 m•kg, 13 ft•lb)



11. Install:
• Exhaust pipe ①

 **Nut (Exhaust Pipe):**
10 Nm (1.0 m•kg, 7.2 ft•lb)
Bolt ② (Muffler Band):
20 Nm (2.0 m•kg, 14 ft•lb)
Bolt ③ (Muffler):
40 Nm (4.0 m•kg, 29 ft•lb)



12. Adjust:

- Clutch cable free play



Free Play:

2~3 mm (0.08~0.12 in)


Refer to the "CLUTCH ADJUSTMENT" section.



FUEL PUMP

PUMP OPERATION INSPECTION


1. Inspect:
 - Fuel pump operation



Pump operation inspection steps:

- Turn the fuel cocks (Right and left) to "ON".
- Disconnect the fuel hose ① from the carburetor. (Fuel pump — Carburetor)
- Place the receptacle under the fuel hose end.
- Turn the main switch to "ON".
- Push the starter switch.
- Check the fuel flows out from the fuel hose ① end.

If fuel does not flow out, refer to "FUEL PUMP INSPECTION" section.




FUEL PUMP INSPECTION


Removal

1. Turn the fuel cocks (Right and left) to "OFF".
2. Disconnect:
 - Fuel hose ① (Fuel tank-Fuel pump)
 - Fuel hose ② (Fuel pump-Carburetor)
 - Pulser hose ③
 - Air vent hose ④ (Fuel pump)
3. Remove:
 - Fuel pump assembly ①






4. Remove:
- Diaphragm cover ①
 - Spring ②
 - Diaphragm ③ (Bypass)




5. Remove:
- Fuel pump cover ① (Upper)
 - Diaphragm ② (Main)
 - Fuel pump cover ③ (Lower)
 - Diaphragm ④ (Main)



Inspection


1. Inspect:
 - Pulser hose ①
 - Air vent hose ② (Fuel pump)
Damage/Clogs/Cracks → Replace.
2. Inspect:
 - Fuel hoses ③
 - Fuel hose joint ④
Damage/Clogs/Cracks → Replace.



3. Inspect:
 - Fuel pump body ①
Contamination → Clean.
Cracks/Damage → Replace fuel pump assembly.


NOTE:

- Use a petroleum based solvent for cleaning.
- Blow out all passage with compressed air.



4. Inspect:


- Diaphragm ① (Bypass)
- Diaphragms ② (Main)
Torn/Fatigue/Cracks → Replace fuel pump assembly.
- Gaskets ③ (Upper and lower)
Torn/Damage → Replace fuel pump assembly.



5. Inspect:

- Valves ①
Clacks/Damage → Replace fuel pump assembly.

- Ⓐ Upper side
- Ⓑ Lower side





Assembly and Installation



1. Install:

- Diaphragm ① (Lower)
- Gaskets ② (Lower)
- Fuel pump cover ③ (Lower)
- Diaphragm ④ (Upper)
- Gaskets ⑤ (Upper)
- Fuel pump cover ⑥ (Upper)

NOTE:

- Gaskets with two tabs should be installed upper side.
- Fuel pump cover with arrow marks should be installed upper side.
- Align the tabs (a) of the fuel pump cover and gaskets with those of the pump body.
- Locate the pulser hose joint (b) of the lower pump cover as shown.
- Install the two longer screws (c) at the location as shown.






2. Install:

- Diaphragm (Bypass) ①
- Spring
- Diaphragm cover

② Fuel pump body

NOTE:

Align the hole ③ on the diaphragm (Bypass) with the pin on fuel pump body.



3. Install:

- Fuel pump assembly

4. Connect:

- Pulser hose
- Fuel hose (Fuel pump-Carburetor)
- Fuel hose (Fuel tank-Fuel pump)
- Air vent hose (Fuel pump)

NOTE:

Be sure to connect the hoses correctly, when connecting.

- A** TO INTAKE MANIFOLD
- B** TO CARBURETOR
- C** FROM FUEL TANK
- D** TO AIR VENT HOSE



FRONT FORK

- ① Cap bolt
- ② O-ring
- ③ Spring seat
- ④ Fork spring (Small)
- ⑤ Spring seat
- ⑥ Fork spring (Large)
- ⑦ Inner fork tube
- ⑧ Guide bush
- ⑨ Piston ring
- ⑩ Rebound spring
- ⑪ Damper rod
- ⑫ Oil lock piece
- ⑬ Dust seal
- ⑭ Retaining clip
- ⑮ Oil seal
- ⑯ Washer
- ⑰ Slide metal
- ⑱ Outer fork tube
- ⑲ Axle holder
- ⑳ Fork boot

FORK OIL (EACH):
CAPACITY:
A 517 cm³ (18.2 Imp oz, 17.5 US oz)
GRADE:
 FORK OIL 10W or EQUIVALENT

FORK SPRING:
B MINIMUM FREE LENGTH:
 593.0 mm (23.3 in)


23 Nm (2.3 m•kg, 17 ft•lb)

C USE NEW ONE

C USE NEW ONE

20 Nm (2.0 m•kg, 14 ft•lb)

8 Nm (0.8 m•kg, 5.8 ft•lb)



**REMOVAL**

1. Elevate the front wheel by placing a suitable stand under the engine.


WARNING:

Support the motorcycle securely so there is no danger of it falling over.

2. Remove:


- Front wheel

Refer to the "FRONT WHEEL — REMOVAL" section.




3. Remove (For left-hand front fork):

- Holder ① (Speedometer cable)
- Holder ② (Brake hose)
- Bolt ③ (Brake caliper)



4. Remove:

- Front fender ①




5. Loosen:


- Pinch bolts ① (Handle crown)
- Cap bolt ②
- Pinch bolts ③ (Under bracket)

WARNING:

Support the fork before loosening the pinch bolts.




6. Remove:
- Front fork




DISASSEMBLY

1. Remove:
- Clamp ① (Fork boot)
 - Fork boot ②




2. Remove:
- Cap bolt ①
 - Fork spring ② (Small)
 - Spring seat ③
 - Fork spring ④ (Large)




3. Drain:
- Fork oil
4. Remove:
- Dust seal ①

NOTE: _____
Use a slotted-head screwdriver, and be careful not to damage the outer fork tube.



5. Remove:
- Retaining clip ①

NOTE: _____
Use a thin screwdriver, and be careful not to scratch the inner fork tube.



6. Remove:

- Bolt ① (Damper rod)
- Washer ② (Copper)

Use the T-Handle ③ and Holder ④ to lock the damper rod.





T-Handle:

90890-01326


Holder:

90890-01294



7. Remove:

- Damper rod ①
- Rebound spring ②
(Out of inner fork tube ③)



8. Remove:


- Inner fork tube

Removal steps:


- Hold the fork leg horizontally.
- Pull out the inner fork tube from the outer tube by forcefully, but carefully, withdrawing the inner fork tube.

CAUTION:

Avoid bottoming the inner tube in the outer tube during the above procedure, as the oil lock piece will be damaged.



9. Remove:
- Oil seal ①
 - Washer ②
 - Guide bush ③
 - Slide metal ④
 - Oil lock piece ⑤




INSPECTION


1. Inspect:
- Inner fork tube ①
 - Outer fork tube ②
- Scratches/Bends/Damage → Replace.


WARNING:

Do not attempt to straighten a bent inner fork tube as this may dangerously weaken the tube.




2. Measure:
- Fork spring (Large) free length ①
- Out of specification → Replace.

	Fork Spring (Large) Free Length:
	603.0 mm (23.7 in)
	Minimum Free Length:
	593.0 mm (23.3 in)




3. Inspect:
- Damper rod ①
Wear/Damage → Replace.
Contamination → Blow out all oil passages with compressed air.
 - Piston ring ②
Wear/Damage → Replace.



4. Inspect:

- Rebound spring ①
 - Fork spring ② (Small)
- Wear/Damage → Replace.



5. Inspect:


- Oil lock piece ①
 - O-ring ② (Cap bolt)
- Damage → Replace.

ASSEMBLY

Reverse the "DISASSEMBLY" procedure.
Note the following points.

NOTE:

- In front fork reassembly, be sure to use following new parts.
 - * Guide bush
 - * Slide bush
 - * Oil seal
 - * Dust seal
- Make sure all components are clean before reassembly.




1. Install:

- Damper rod ①

CAUTION:

Allow the damper rod to slide slowly down the inner fork tube until it protrudes from the bottom, being careful not to damage the inner fork tube.




2. Install:
 - Oil lock piece ①
3. Lubricate:
 - Inner fork tube ② (Outer surface)




FORK OIL 10W OR EQUIVALENT

③ Outer fork tube




4. Tighten:
 - Bolt (Damper rod)
 Use the T-Handle ① and Holder ② to lock the damper rod.




T-Handle:
90890-01326

Holder:
90890-01294




Bolt (Damper Rod):
20 Nm (2.0 m•kg, 14 ft•lb)

Apply LOCTITE®.




5. Install:
 - Guide bush ①
 Use the Fork Seal Driver Weight ② and Adapter ③.



Fork Seal Driver Weight:
90890-01367

Adapter:
90890-01381

④ Inner fork tube
⑤ Outer fork tube




6. Install:

- Oil seal ①
Use the Fork Seal Driver Weight ② and Adapter ③.



Fork Seal Driver Weight:
90890-01367
Adapter:
90890-01381

④ Washer



7. Install:

- Dust seal ①
Use the Fork Seal Driver Weight ② and Adapter ③.



Fork Seal Driver Weight:
90890-01367
Adapter:
90890-01381


④ Retaining clip

8. Fill:

- Front fork




Fork Oil Capacity:
517 cm³ (18.2 Imp oz,
17.5 US oz)
Grade:
Fork Oil 10W or Equivalent



NOTE: _____

After filling the front fork with fork oil, slowly pump the front fork up and down to distribute oil.



9. Measure:

- Oil level (a)
- Out of specification → Add or reduce oil.




Oil Level:
 120 mm (4.72 in)
 From the top of the inner fork tube.

NOTE:

- When measuring the oil level, fully compress the inner fork tube without the fork spring.
- Place the front fork on upright position.

10. Before installing the front fork, temporary tighten the cap bot.



INSTALLATION


Reverse the "REMOVAL" procedure.
 Note the following points.

1. Install:

- Front fork
- Temporary tighten the pinch bolts.

NOTE:

Position the inner fork tube end in such a way that it is flush (a) with the top of the handle crown.




2. Tighten:


- Pinch bolts (1) (Under bracket)
- Cap bolt (2)
- Pinch bolts (3) (Handle crown)




Pinch Bolt (Under Bracket):
 23 Nm (2.3 m•kg, 17 ft•lb)
Cap Bolt:
 23 Nm (2.3 m•kg, 17 ft•lb)
Pinch Bolt (Handle Crown):
 23 Nm (2.3 m•kg, 17 ft•lb)





3. Install:
 • Front fender

	Bolt (Front Fender): 8 Nm (0.8 m•kg, 5.8 ft•lb)
---	---




4. Install:
 • Brake caliper ①


	Bolt (Brake Caliper): 35 Nm (3.5 m•kg, 25 ft•lb)
---	--



5. Install:
 • Front wheel

	Nut ① (Wheel Axle): 110 Nm (11.0 m•kg, 80 ft•lb)
	Nut ② (Axle Holder): 8 Nm (0.8 m•kg, 5.8 ft•lb)

Refer to the "FRONT WHEEL — INSTALLATION" section.








6. Adjust:
 • Air pressure (Front fork)

Standard Air Pressure: Zero kPa (Zero kg/cm ² , Zero psi)
Maximum Air Pressure: 100 kPa (1.0 kg/cm ² , 14 psi)

Refer to the "FRONT FORK ADJUSTMENT" section in the CHAPTER 3.

ELECTRICAL

XT600Z(U) CIRCUIT DIAGRAM



- ① CDI magneto
- ② Rectifier/Regulator
- ③ Main switch
- ④ Clutch switch
- ⑤ CDI unit
- ⑥ Ignition coil
- ⑦ Spark plug
- ⑧ Pick-up coil
- ⑨ Sidestand switch
- ⑩ Neutral relay
- ⑪ "NEUTRAL" indicator light
- ⑫ Neutral switch
- ⑬ Starting circuit cut-off relay
- ⑭ Flasher relay
- ⑮ "TURN" switch
- ⑯ Horn
- ⑰ "HORN" switch
- ⑱ "TURN" indicator light
- ⑲ Flasher light (Right)
- ⑳ Flasher light (Left)
- ㉑ Tail/Brake light
- ㉒ Auxiliary light
- ㉓ Meter light
- ㉔ Front brake switch
- ㉕ Rear brake switch
- ㉖ Headlight
- ㉗ "HIGH BEAM" indicator light
- ㉘ "LIGHTS" switch
- ㉙ "LIGHTS" (Dimmer) switch
- ㉚ "ENGINE STOP" switch
- ㉛ "START" switch
- ㉜ Starting motor
- ㉝ Starter relay
- ㉞ Battery
- ㉟ Fuse

- A D, F, B, S, GR, P, E
- B SF, NL
- C N, S
- D I, GB, DK
- E Except for I, GB, DK
- F I, GB, DK

COLOR CODE

B	Black	Y	Yellow
Br	Brown	B/W	Black/White
Ch	Chocolate	B/Y	Black/Yellow
Dg	Dark green	Br/W	Brown/White
G	Green	L/W	Blue/White
L	Blue	G/Y	Green/Yellow
O	Orange	L/R	Blue/Red
P	Pink	L/Y	Blue/Yellow
R	Red	W/G	White/Green
Sb	Sky blue	W/R	White/Red
W	White	R/W	Red/White



ELECTRICAL COMPONENTS

- ① Wireharness
- ② Main switch
- ③ Ignition coil
- ④ Rectifier/Regulator
- ⑤ Battery
- ⑥ CDI unit
- ⑦ Fuse

IGNITION COIL:

PRIMARY COIL RESISTANCE:

0.15 ~ 0.21Ω at 20°C (68°F)

SECONDARY COIL RESISTANCE:

3.8 ~ 5.8kΩ at 20°C (68°F)


BATTERY:

CAPACITY:

12V 12AH


SPECIFIC GRAVITY:

1.280





- ① Rear brake switch
- ② Horn
- ③ Neutral switch
- ④ Sidestand switch
- ⑤ Flasher relay
- ⑥ Starter relay
- ⑦ Starting circuit cut-off relay
- ⑧ Neutral relay



TROUBLESHOOTING

QUICK REFERENCE CHART

Trouble mode	Erroneous operation of starter motor.					Starter motor starts but no ignition.			Malfunction during operations.															
	Inspection parts	Gear	Clutch lever		Side-stand	Starter motor	Starter motor runs weakly.	Relay clicks and starter motor doesn't run.	With main switch on, Starter motor runs.	Starter motor runs.	Engine stops during operation.	When warm, engine stops and can't be restarted.	When handlebar is steered, engine stops.	Engine malfunctions at high speed.	Knocking	Engine stops in raining weather.	Electric shock.							
		N	HOLD	RELEASE	DOWN													UP	STOP	RUN	STOP	RUN	STOP	RUN
		IN GEAR	—	—	—													—	STOP	RUN	STOP	RUN	STOP	RUN
[A] BATTERY	1					1	1																	
[B] FUZE	2																							
[C] STARTER MOTOR	3					2	2																	
[D] STARTER RELAY	4						3	1																
[E] MAIN SWITCH	5																							
[F] STARTER SWITCH	6																							
[G] "ENGINE STOP" SWITCH	7																							
[H] NEUTRAL SWITCH	8																							
[I] STARTING CIRCUIT CUT-OFF RELAY	9																							
[J] CLUTCH SWITCH			1	*1	1																			
[K] SIDESTAND SWITCH		*1	*2	*2						*6	*6													
[L] SPARK PLUG									1	*1	1	1	1		1	1								
[M] SPARK PLUG CAP									2	*2	2	2	2		2	2	1							
[N] IGNITION COIL									3	*3	3	3	3	1	3	3	2							
[O] SOURCE COIL									4	*4	4	4	4	2										
[P] PICKUP COIL									5	*5	5	5	5	3										
[Q] NEUTRAL RELAY		*2		*3					6	*7	*7	*6												
[R] WIREHARNESH	10	*3	3	*4	2				7	*8	8	7	6	1		4								
[S] CDI UNIT	11	*4	4	*5	3				8	*9	9	8	7		4	4	5							

*: Except for Oceania and South Africa.

NOTE:

- [A] ~ [Q] & [S] indicates the location of the parts-connectors for checking.
- Use the following special tools in this troubleshooting.


Pocket Tester:
90890-03112






Dynamic Spark Tester:
90890-03144

HOW TO USE CHART:

- Step 1. Look for an approprial trouble mode from the motorcycle phenomenon.
- Step 2. Procced to checking in the ascending order of the numbers.
- Step 3. Look for the location by reference to the "LOCATION OF PARTS-CONNECTORS". (P.82)
- Step 4. Go to further details of checking. (P. 83 ~ 102)

LOCATION OF PARTS-CONNECTORS





GENERAL INFORMATION

Connection Inspection

Dealing with stains, rust, moisture, etc. on the connector.

1. Disconnect:
 - Connector
2. Dry each terminal by an air blower.
3. Connect and disconnect the connector two to three times.
4. Pull the lead to check that it will not come off.
5. If the terminal comes off, bend up the pin ① and reinsert the terminal into connector.
6. Connect:
 - Connector
7. Check for continuity by a tester.

NOTE:

- If there is no continuity, clean the terminals.
- Be sure to perform the above steps 1 to 7 when checking the wireharness.
- When replacing the CDI unit, be sure to check its connector.
- For a field remedy, use a contact revitalizer available on the market.
- Use the tester on the connector as shown.



Switch Inspection



1. Before checking the switch, be sure to turn it on and off several times.
2. Check the switch two or three times. If a different resistance value is indicated even once, replace the switch.

IGNITION AND STARTING CIRCUIT SYSTEM


Features

- In neutral, the starter motor will run in any condition of the clutch lever and sidestand.
- In any shifted gear, the starter motor will not run unless the clutch lever is gripped and the sidestand is folded up.
- The engine will stall, if the sidestand is put down during operation in any shifted gear.






SPECIFIC GRAVITY VS LIQUID TEMP.



INSPECTION PARTS

A Battery Inspection

- Inspect:
 - Battery terminal
 - Battery voltage

	Tester lead (Red)	Tester lead (Black)	Battery voltage	Range
	Positive ①	Negative ②	12 ~ 14V	DC20V

Out of specification → Recharge battery or replace battery.

- Inspect:
 - Fluid level
 - Specific gravity


Specific Gravity:
1.260 ~ 1.280 at 20°C (68°F)

Out of specification → Recharge battery or replace battery.

Replace the battery if:


- Battery voltage will not rise to a specific value or bubbles fail to rise even after many hours of charging.
- Sulfation of one or more cells occurs, as indicated by the plates turning white, or an accumulation of material exists in the bottom of the cell.
- Specific gravity readings after a long, slow charge indicate one cell to be lower than the rest.
- Warpage or buckling of plates or insulators is evident.

Refer to the "BATTERY IN SPECITION" section in the CHAPTER 3.



B Fuse Inspection

- Inspect:
 - Fuse for continuity
 - Fuse holder

	Tester lead (Red)	Tester lead (Black)	Continuity	Range
	Fuse holder lead ①	Fuse holder lead ②	Continuous	Ω × 1




Non-continuous → Replace fuse or fuse holder.

Loose terminal → Replace fuse or fuse holder.

Amperage for Individual:
20A

Refer to the "FUZE INSPECTION" section in the CHAPTER 3.



C Starter Motor Inspection

1. Main switch to "ON".
2. Inspect:
 - Starter motor
 - Use the jumper lead ①.
 - Starter motor does not run → Go on to steps 3 to 8.

WARNING:

- For inspection, make sure that the engine is in neutral.
- This check is likely to produce sparks, so be sure that no flammable gas or fluid is in the vicinity.
- If the jumper lead is in contact with the frame, it will cause a heavy shortcircuit.

3. Measure:
 - Brush length (Each)



Minimum Brush Length:
5.0 mm (0.20 in)

Out of specification → Replace brush assembly.

Damaged surface of contact with commutator → Replace brush assembly



4. Inspect:
 - Brush spring







Brush Spring Pressure:
680 ~ 920 g (23.9 ~ 32.4 oz)

Out of specification → Replace brush assembly.

Fatigue/Damage → Replace brush assembly.





5. Inspect:

- Commutator condition
Damaged, worn, and burned surface of commutator → Replace armature coil

6. Inspect:

- Armature coil for continuity

	Tester lead (Red)	Tester lead (Black)	Continuity	Range
	Commutator	Commutator	Continuous	$\Omega \times 1$
	Commutator	Iron core	Non-continuous	$\Omega \times 1k$

Bad condition → Repair armature coil or replace armature coil.

7. Measure:

- Commutator diameter



Outside Diameter Limit:
27 mm (1.06 in)

Out of specification → Replace armature coil.

8. Measure:



- Mica undercut (a):
Out of specification → Scrape mica using a hacksaw blade.



Mica Undercut (a):
0.7 mm (0.028 in)

NOTE: _____

The mica insulation of the commutator must be undercut to ensure proper operation of the commutator.




D Starter Relay Inspection

1. Inspect:
 - Starter relay ①
 - Use the jumper leads ②.

Starter motor does not run → Go on to steps 2 and 3.

2. Disconnect:
 - Starter relay leads and connector
3. Inspect:
 - Starter relay for continuity

	Tester lead (Red)	Tester lead (Black)	Voltage applied	Voltage not applied	Range
	Terminal ①	Terminal ②	×	○	$\Omega \times 1$
○: Continuity ×: Nocontinuity					

Bad condition → Replace starter relay.


E Main Switch Inspection


1. Inspect:
 - Flasher operation

Flasher does not move → Go on to steps 2 and 3.


2. Disconnect:
 - Main switch coupler

3. Inspect:
 - Main switch for continuity



	Tester lead (Red)	Tester lead (Black)	ON	OFF	Lock	P	Range
	Red ①	Brown ②	○	×	×	×	$\Omega \times 1$
	Black/White ③	Black ④	×	○	○	○	
○: Continuity ×: Nocontinuity							

Bad condition → Replace main switch.




F Starter Switch Inspection

1. Disconnect:
 - Starter switch connector
2. Inspect:
 - Starter switch for continuity

	Tester lead (Red)	Tester lead (Black)	OFF	PUSH	Range
	Blue/White ①	Red/White ②	×	○	Ω×1
○: Continuity ×: Nocontinuity					

Bad condition → Replace starter switch.




G "ENGINE STOP" Switch Inspection

1. Inspect:
 - "ENGINE STOP" switch for continuity






	Tester lead (Red)	Tester lead (Black)	OFF	RUN	Range
	Blue/White ①	Black ②	×	○	Ω×1
○: Continuity ×: Nocontinuity					

Bad condition → Replace "ENGINE STOP" switch.



H Neutral Switch Inspection

1. Main switch to "ON".
2. Shift in neutral.
3. Inspect:
 - "NEUTRAL" indicator light ①
 Not glowing → Go on to steps 4 and 5.



4. Disconnect:
 - Neutral switch connector
5. Inspect:
 - Neutral switch for continuity

	Tester lead (Red)	Tester lead (Black)	Neutral	In gear	Range
	Sky blue ①	Ground ②	○	×	$\Omega \times 1$
○: Continuity ×: Nocontinuity					

Bad condition → Replace neutral switch.

I Starting Circuit Cut-Off Relay Inspection

1. Main switch to "ON".
2. Shift in other than neutral.
3. Sidestand is folded up.
4. Inspect:
 - Starting circuit cut-off relay for operation clicks
 - No clicks can be heard even if the clutch lever is held → Go on to steps 5 and 6.
5. Disconnect:
 - Starting circuit cut-off relay connector
6. Inspect:
 - Starting circuit cut-off relay for continuity

	Tester lead (Red)	Tester lead (Black)	Voltage applied	Voltage not applied	Range
	Terminal ①	Terminal ②	×	○	$\Omega \times 1$
○: Continuity ×: Nocontinuity					


Bad condition → Replace starter relay.

NOTE:

Apply the voltage as shown.

J Clutch Switch Inspection


1. Main switch to "ON".
2. Shift in other than neutral.
3. Sidestand is folded up.
4. Inspect:
 - Starting circuit cut-off relay for operation clicks
 - No clicks can be heard even if the clutch lever is held → Go on to steps 5 and 6.



5. Disconnect:
 - Clutch switch connector
6. Inspect:
 - Clutch switch for continuity

	Tester lead (Red)	Tester lead (Black)	Hold	Release	Range
	Black/ Yellow ①	Black ②	○	×	$\Omega \times 1$
○: Continuity ×: Nocontinuity					

Bad condition → Replace clutch switch.



K Sidestand switch inspection


1. Main switch to "ON".
2. Shift in other than neutral.
3. Hold the clutch lever.
4. Inspect:
 - Starting circuit cut-off relay for operation clicks

No clicks can be heard even if the sidestand is folded up → Go on to 5 and 6.



5. Disconnect:
 - Sidestand connector
6. Inspect:
 - Sidestand switch for continuity

	Tester lead (Red)	Tester lead (Black)	Up	Down	Range
	Blue/ Yellow ①	Black ②	○	×	$\Omega \times 1$
○: Continuity ×: Nocontinuity					



L Spark Plug Inspection

1. Inspect:

- Electrode ①
Wear/Damage → Replace spark plug.
- Insulator ②
Abnormal color → Replace spark plug.

2. Measure:

- Plug gap ①
Use a Wire Gauge or Feeler Gauge



Spark Plug Gap:

0.8 ~ 0.9 mm (0.03 ~ 0.04 in)

Out of specification → Replace spark plug.

Refer to the "SPARK PLUG INSPECTION" section in the CHAPTER 3.

3. Measure:



- Spark gap
Use a Dynamic Spark Tester ①.



Minimum Spark Gap:

6 mm (0.24 in)

Meets specification → Replace spark plug



M Spark Plug Cap Inspection

1. Inspect:

- Spark plug cap resistance




Spark Plug Cap Resistance:


8 ~ 12kΩ at 20°C (68°F)

Out of specification → Replace spark plug cap.

NOTE:


Check the spark plug lead for any fault when fitting the spark plug cap to it. If any fault is found, cut the spark plug lead 5 mm (0.197 in) at its tip.






N Ignition Coil Inspection


1. Disconnect:
 - Primary coil connector
2. Inspect:
 - Primary coil resistance

	Tester lead (Red)	Tester lead (Black)	Speciflicated resistance	Range
	Terminal (Orange) ①	Terminal (Black) ②	0.15 ~ 0.20Ω at 20°C (68°F)	Ω × 1


Out of specification → Replace ignition coil.



3. Inspect:
 - Secondary coil resistance


	Tester lead (Red)	Tester lead (Black)	Speciflicated resistance	Range
	Spark plug lead ①	Terminal (Black) ②	3.8 ~ 5.8kΩ at 20°C (68°F)	Ω × 1k

Out of specification → Replace ignition coil.




O Source Coil Resistance Inspection

1. Disconnect:
 - Source coil connector
2. Inspect:
 - Source coil resistance

	Tester lead (Red)	Tester lead (Black)	Speciflicated resistance	Range
	Red ①	Brown ②	115 ~ 173Ω at 20°C (68°F)	Ω × 10

Out of specification → Replace source coil.




P Pickup Coil Resistance Inspection

1. Disconnect:
 - Pickup coil connector
2. Inspect:
 - Pickup coil (For high speed)

	Tester lead (Red)	Tester lead (Black)	Speciflicated resistance	Tester selection
	Blue/ Yellow ①	Black/ Yellow ②	92 ~ 138Ω at 20°C (68°F)	Ω × 10


Out of specification → Replace pickup coil.



3. Inspect:
 - Pickup coil (For low speed)


	Tester lead (Red)	Tester lead (Black)	Speciflicated resistance	Tester selection
	Green/ White ①	Black/ Yellow ②	92 ~ 138Ω at 20°C (68°F)	Ω × 10

Out of specification → Replace pickup coil.




Q Neutral Relay Inspection

1. Disconnect:
 - Starting circuit cut-off relay connector



2. Shift in neutral.

3. Inspect:
 - Neutral relay for operation clicks
 - No clicks can be heard even if the main switch is turned on → Go on to 4 and 5.



4. Disconnect:
 - Neutral relay connector
5. Inspect:
 - Neutral relay for continuity

	Tester lead (Red)	Tester lead (Black)	Voltage applied	Voltage not applied	Range
	Terminal ①	Terminal ②	×	○	Ω × 1
○: Continuity ×: Nocontinuity					



Bad condition → Replace neutral relay.



R Wireharness Inspection

Starter System Check: ① ② ③ ④ ⑤ ⑥ ⑦ ⑧ ⑨ ⑩ ⑪ ⑫ ⑬ ⑭

Ignition System Check: ⑮ ⑯




NOTE:


- Check the continuity with the connector connected, as shown.
- For the connector shape, refer to the color wiring diagram.



IGNITION AND STARTING SYSTEM

ELEC





S CDI Unit Replacement

1. Inspect:

- Connection

Refer to page 81.

2. Replace:


- CDI unit



STARTER MOTOR

- ① Starter motor lead
- ② O-ring
- ③ Yoke assembly
- ④ Armature coil assembly
- ⑤ Brush assembly
- ⑥ Washer

A	COMMUTATOR UNDER CUT: 0.7 mm (0.028 in)
B	COMMUTATOR DIAMETER WEAR LIMIT: 27 mm (1.06 in)
C	BRUSH WEAR LIMIT: 5.0 mm (0.20 in)






Removal

1. Remove:

- Starter motor drive gear
- Starter motor
- Starter motor bracket


Refer to "ENGINE OVERHAUL-STARTER MOTOR" section.



Disassembly


1. Remove:

- Yoke assembly



2. Remove:

- Armature coil assembly




3. Remove:

- Brush springs ①


Assembly

Reverse the "Removal" and "Disassembly" procedure.


Note the following points.



1. Install:
 - Brushes ①




2. Install:
 - Armature coil assembly ①




3. Install:
 - Brush springs ①

CAUTION:


- Fit the spring ① over the spring holder ② as per the illustrated location.
- Take care not to wind the spring too much; otherwise, it may be subjected to a permanent distortion.



4. Install:
 - O-rings (New) ①




5. Apply:
 - Lithium soap base grease
(To oil seal and bearing)




6. Install:
 • Cover ①

NOTE: _____
 Align the projection ② on the brush plate with the slot ③ on cover ①.



7. Install:
 • Yoke assembly

NOTE: _____
 Align the match marks ① on the bracket with the match marks ② on the housing.



8. Install:
 • O-ring (New) ①

NOTE: _____
 Apply a grease lightly.




IGNITION AND STARTING SYSTEM





**LIGHTING SYSTEM
CIRCUIT DIAGRAM**



Below circuit diagram shows lighting system.





NOTE: _____
 For the color codes, see page 78.

- ③ Main switch
- ① Tail/Brake light
- ② Auxiliary light
- ③ Meter light
- ⑥ Headlight
- ⑦ "HIGH BEAM" indicator light
- ⑧ "LIGHTS" switch
- ⑨ "LIGHTS" (Dimmer) switch
- ④ Battery
- ⑤ Fuse





TROUBLESHOOTING

HEADLIGHT, TAILLIGHT, AUXILIARY LIGHT AND/OR METER LIGHT DO NOT COME ON.

Procedure


Check;

1. Fuse
2. Battery
3. Main switch
4. "LIGHTS" switch
5. Wiring connection
(Entire lighting system)


NOTE:

- Remove the following parts before troubleshooting.

1) Seat	4) Front cowl
2) Side cover (Left)	5) Headlight lens unit
3) Fuel tank	6) Rear cover
- Use the following special tool(s) in this troubleshooting.



Pocket Tester:
P/N. 90890-03112





2. Battery

Check the battery condition.
Refer to the "BATTERY INSPECTION" section in the CHAPTER 3.

Specific Gravity:
1.280 at 20°C (68°F)

INCORRECT

- Refill battery fluid.
- Clean battery terminals.
- Recharge or replace battery.



3. Main switch

- Disconnect the main switch coupler (Red, Brown, Black, Blue and Blue/Red) from the wireharness.
- Connect the Pocket Tester ($\Omega \times 1$) to the main switch leads.
- Check the main switch for continuity.

A Tester (+) Lead → Red ① Lead
Tester (-) Lead → Brown ② Lead

Switch position	Good condition	Bad condition		
ON	○	×	×	○
OFF	×	○	×	○


B Tester (+) Lead → Blue ③ Lead
Tester (-) Lead → Blue/Red ④ Lead

Switch position	Good condition	Bad condition		
ON	○	×	×	○
OFF	×	○	×	○

C Tester (+) Lead → Red ① Lead
Tester (-) Lead → Blue/Red ④ Lead

Switch position	Good condition	Bad condition		
PO	○	×	×	○
OFF	×	○	×	○

○: Continuity ×: Nocontinuity



BAD CONDITION

Main switch is faulty, replace it.




GOOD CONDITION



4. "LIGHTS" switch

- Disconnect the handlebar switch (Left) coupler (Pink, Green, Yellow, Blue, Black, Dark green, Brown/White and Chocolate) and Brown lead connector from the wireharness.
- Connect the Pocket Tester ($\Omega \times 1$) to the "LIGHTS" switch leads.

Tester (+) Lead \rightarrow Brown ① Lead
 Tester (-) Lead \rightarrow Blue ② Lead



- Turn the "LIGHTS" switch to "ON", "PO" and "OFF".
- Check the "LIGHTS" switch for continuity.

Switch position	Good condition		Bad condition		
	○	×	×	×	○
ON	○	×	×	×	○
PO	○	×	×	×	○
OFF	×	○	×	×	○

○: Continuity ×: Nocontinuity

BAD CONDITION

"LIGHTS" switch is faulty, replace handlebar switch (Left).

GOOD CONDITION

5. Wiring connection

Check the entire lighting system for connections.
 Refer to the "WIRING DIAGRAM" section.

POOR CONNECTION

Correct.

CORRECT





Check condition of each circuit for lighting system.
Refer to "LIGHTING SYSTEM CHECK" section.

LIGHTING SYSTEM CHECK

1. Headlight "HIGH BEAM" indicator light bulb do not come on.

1. Headlight bulb

- Remove the headlight bulb(s).
- Connect the Pocket Tester ($\Omega \times 1$) to the headlight bulb.

Tester (+) Lead \rightarrow Terminal ①
Tester (-) Lead \rightarrow Terminal ③

Tester (+) Lead \rightarrow Terminal ②
Tester (-) Lead \rightarrow Terminal ③

A

B

A Left **B** Right (For D, F, B, S, GR, P, E)

- Check the bulb for continuity.

1. "HIGH BEAM" indicator light bulb

- Remove the "HIGH BEAM" indicator light bulb from the tachometer.
- Connect the Pocket Tester ($\Omega \times 1$) to the bulb.

- Check the bulb for continuity.

NOCONTINUITY

Replace bulb(s).

CONTINUITY

2. Bulb socket (Lighting harness)

- Install the bulb to the bulb socket.
- Disconnect the bulb socket (Indicator harness) coupler (Yellow, Dark green, Brown, Blue, Sky blue, Chocolate and Black) from the bulb socket (Lighting harness).
- Disconnect the bulb socket (Lighting harness) coupler (Dark green, Green, Chocolate, Brown, Black and Yellow) from the wireharness.
- Connect the Pocket Tester ($\Omega \times 1$) to the bulb socket (Lighting harness) coupler.

2. Bulb socket (Indicator harness)

- Install the bulb to the bulb socket.
- Remove the headlight bulb(s).
- Disconnect the bulb socket (Lighting harness) coupler (Dark green, Green, Chocolate, Brown, Black and Yellow) from the wireharness.
- Connect the Pocket Tester ($\Omega \times 1$) to the bulb socket (Lighting harness) coupler.



A Tester (+) Lead → Yellow ① Lead
Tester (-) Lead → Black ② Lead

B Tester (+) Lead → Green ③ Lead
Tester (-) Lead → Black ② Lead

A "HI" High beam and "HIGH BEAM" indicator light
B "LO" Low beam
• Check the bulb socket for continuity.


NOCONTINUITY

Bulb socket is faulty, repair or replace it.

CONTINUITY

3. "LIGHTS" (Dimmer) switch

- Disconnect the handlebar switch (Left) copler (Pink, Green, Yellow, Blue, Black, Dark green, Brown/White and Chocolate) from the wireharness.
- Turn the "LIGHTS" switch to "ON".
- Connect the Pocket Tester ($\Omega \times 1$) to the "LIGHTS" (Dimmer) switch.



- Turn the "LIGHTS" (Dimmer) switch to "HI" and "LO".
- Check the "LIGHTS" (Dimmer) switch for continuity.

A Tester (+) Lead → Blue ① Lead
Tester (-) Lead → Green ② Lead

Switch position	Good condition	Bad condition		
HI	×	○	×	○
LO	○	×	×	○

B Tester (+) Lead → Blue ① Lead
Tester (-) Lead → Yellow ③ Lead

Switch position	Good condition	Bad condition		
HI	○	×	×	○
LO	×	○	×	○

○: Continuity ×: Nocontinuity

BAD CONDITION

"LIGHTS" (Dimmer) switch is faulty, replace handlebar switch (Left).

GOOD CONDITION


4. Wiring connection

Check the entire lighting system for connections. Refer to the "WIRING DIAGRAM" section.

2. Meter light does not come on.

1. Bulb

- Remove the meter light bulb(s) from the meter.
- Connect the Pocket Tester ($\Omega \times 1$) to the bulb.



- Check the bulb for continuity.

NOCONTINUITY

Replace bulb(s).

CONTINUITY


*



2. Bulb socket (Indicator harness)

- Install the bulb to the bulb socket.
- Disconnect the bulb socket (Indicator harness) coupler (Yellow, Dark green, Brown, Blue, Sky blue, Chocolate and Black) from the lighting harness.
- Connect the Pocket Tester ($\Omega \times 1$) to the bulb socket (Indicator harness) coupler terminals.

Tester (+) Lead → Blue ① Lead
 Tester (-) Lead → Black ② Lead



- Check the bulb socket for continuity.

4. Wiring connection

Check the entire lighting system for connections. Refer to the "WIRING DIAGRAM" section.

NOTE: _____
 Perform a continuity test on the right and left circuitries with one bulb connected at a time.


NOCONTINUITY

Bulb socket is faulty, replace or repair it.

CONTINUITY



3. Taillight does not come on.



*




3. Wiring connection

Check the entire lighting system for connections. Refer to the "WIRING DIAGRAM" section.

4. Auxiliary light does not come on.

1. Bulb

- Remove the auxiliary light bulb(s) from the headlight body.
- Connect the Pocket Tester ($\Omega \times 1$) to the auxiliary light bulb.



- Check the auxiliary light bulb for continuity.

NOCONTINUITY


Replace auxiliary light bulb(s).

CONTINUITY

2. Bulb socket

- Install the bulb(s) to the bulb socket(s).
- Disconnect the bulb socket coupler(s) (Blue/Red and Black) from the lighting harness.
- Connect the Pocket Tester ($\Omega \times 1$) to the bulb socket coupler.

Tester (+) Lead → Blue/Red ① Lead
Tester (-) Lead → Black ② Lead



NOCONTINUITY

Bulb socket is faulty, repair or replace it.

CONTINUITY


3. Wiring connection

Check the entire lighting system for connections. Refer to the "WIRING DIAGRAM" section.


XT600Z(U) WIRING DIAGRAM

F-14


(E) (D) (B) (S) (F) (GR) (P)





(SF) (NL)



(GB) (DK) (I)



(N) (CH)



- ① "START" switch
- ② "ENGINE STOP" switch
- ③ Ignition coil
- ④ Spark plug
- ⑤ CDI unit
- ⑥ CDI magneto
- ⑦ Neutral switch
- ⑧ Neutral relay (For Europe)
- ⑨ Starting circuit cut-off relay
- ⑩ Starter relay
- ⑪ Starting motor
- ⑫ Battery
- ⑬ Fuse
- ⑭ Rear flasher light (R)
- ⑮ Tail/Brake light
- ⑯ Rear flasher light (L)
- ⑰ Sidestand switch (For Europe)
- ⑱ Rectifier/Regulator
- ⑲ Rear brake switch
- ⑳ Flasher relay
- ㉑ "LIGHTS" (Dimmer) switch
- ㉒ "TURN" switch
- ㉓ "HORN" switch
- ㉔ "LIGHTS" switch
- ㉕ Horn
- ㉖ Main switch
- ㉗ Front flasher light (L)
- ㉘ Front flasher light (R)
- ㉙ Headlight
- ㉚ Auxiliary light
- ㉛ "HIGH BEAM" indicator light
- ㉜ "TURN" indicator light
- ㉝ "NEUTRAL" indicator light
- ㉞ Meter light
- ㉟ Clutch switch
- ㊱ Front brake switch

COLOR CODE

BBlack	B/W . .Black/White
BrBrown	B/Y . .Black/Yellow
ChChocolate	Br/W . .Brown/White
DgDark green	G/W . .Green/White
GGreen	G/Y . .Green/Yellow
LBlue	L/B . .Blue/Black
OOrange	L/R . .Blue/Red
PPink	L/W . .Blue/White
RRed	L/Y . .Blue/Yellow
SbSky blue	R/W . .Red/White
WWhite	W/G . .White/Green
YYellow	